


Automotive Mode: Understanding Your GPSMAP 620/640

NOTE: North American maps are preloaded on the GPSMAP 640. To use the automotive functions of the GPSMAP 620, the GPSMAP 620 Automotive Kit is required.


- 1 GPS satellite strength.
- 2 Usage mode. Touch this icon to change modes.
- 3 Battery status.
- 4 Current time. Touch to change time settings.
- 5 Touch to find a destination.
- 6 Touch to view the map.
- 7 Touch to adjust the volume.
- 8 Touch to use the tools such as **Settings** and **Custom Routes**.




Automotive Mode: Menu page

Automotive Mode: Finding Your Destination


The Where To? menu provides several different categories for you to use when searching for addresses, cities, and other locations. The detailed maps (either preloaded to your GPSMAP 640 or optionally loaded to your GPSMAP 620) contain millions of points of interest, such as restaurants, hotels, and auto services.



1. Touch **Where To?**.
2. Select a category.



3. Select a subcategory.
4. Select a destination.



5. Touch **Go!**.

TIP: Touch and to see more choices.

Automotive Mode: Adding a Stop

You can add a stop (called a Via Point) to your route. The GPSMAP 620/640 gives you directions to the Via Point and then to your final destination.

1. With a route active, touch **Menu > Where To?**.
2. Search for the extra stop.
3. Touch **Go!**.
4. Touch **Add as Via Point** to add this stop before your destination. Touch **Set as New Destination** to make this your final destination.

Automotive Mode: Taking a Detour

1. With a route active, touch **Menu**.
2. Touch **Detour**.

The GPSMAP 620/640 attempts to get you back on your original route as quickly as possible. If the route you are currently taking is the only reasonable option, the GPSMAP 620/640 might not calculate a detour.

Automotive Mode: Stopping the Route

1. With a route active, touch **Menu**.
2. Touch **Stop**.

Automotive Mode: Adjusting the Volume

From the Menu page, touch **Volume**. Touch and to adjust the volume. Touch the box next to **Mute** to mute all audio.

Automotive Mode: Setting a Home Location

Set your home location for the place you return to most often.

1. Touch **Where To? > Go Home**.
2. Select an option:
 - Enter your address.
 - Use your current location.
 - Choose from a list of recently found locations.

Automotive Mode: Going Home

To navigate home after you have set your home location, touch **Where To? > Go Home**.

GPSMAP® 620/640

quick reference guide



Mount Your GPSMAP 620/640

1. Flip up the locking tab on top of the mounting bracket.
2. Fit the bottom of the device into the cradle.
3. Tilt the device back until it stops.
4. Flip down the locking tab to hold the device in the mounting bracket.



Placing the GPSMAP 620/640 in the Mounting Bracket

To remove the GPSMAP 620/640 from the mounting bracket:

1. Flip up the locking tab on top of the mounting bracket.
2. Tilt the device forward, and lift it out of the mounting bracket.

Powering the GPSMAP 620/640 On and Off

Power on the GPSMAP 620/640:

- If the mounting bracket on your boat or in your car is connected to power, the device powers on when you place it in the mount.
- To power on the device manually, press and hold the **Power** key until the Garmin logo appears on the screen.



Power off the GPSMAP 620/640:

- When you remove the device from the mounting bracket, you will be prompted to continue on battery power. Touch **Turn Off** to power off the device.
- To power off the device manually, press and hold the **Power** key until the unit powers off.

NOTE: If you manually power off the device while it is connected to a power source, it will continue to charge the battery

Inserting a Secure Digital (SD) Card

1. Turn the locking ring and remove the battery pack. The SD card slot is in the bottom of the battery compartment, on the opposite side from the battery contacts.
2. Place an SD card into the opening with the label showing and with the SD card contacts facing away from the battery contacts.
3. Slide the SD card into the SD card slot, and press until it clicks and locks in place.
4. Insert the battery pack.



Inserting an SD Card

To remove an SD card:

1. Remove the battery.
2. Press in on the SD card until it clicks and releases from the SD card slot.
3. Remove the SD card.

Marine Mode: Acquiring Satellites

1. Go outdoors to an open area, away from tall buildings and trees.
2. Turn on your GPSMAP 620/640.

Acquiring satellite signals can take a few minutes. The bars indicate satellite strength. When at least one of the bars is green, your GPSMAP 620/640 has acquired satellite signals. Now you can select a destination and navigate to it.

Marine Mode: Understanding Your GPSMAP 620/640

- 1 Usage mode. A boat icon represents marine mode, and a car icon represents automotive mode. Touch this icon to change modes.
- 2 XM[®] satellite strength (only available on the GPSMAP 640 when using an optional GXM 40 XM antenna).
- 3 GPS satellite strength.
- 4 Battery status.
- 5 Current time.
- 6 Home screen categories and actions. Touch an icon to view the associated menu or perform the associated action.




Marine Mode: Home screen

Marine Mode: Navigating Directly to a Destination

1. From the Home screen, touch **Charts** > **Navigation Chart**.
2. On the Navigation chart, touch the place you would like to navigate to.

NOTE: Touch and to zoom in and out. Touch anywhere on the chart and drag it to pan the map.

3. When the pointer icon is on the location you want to navigate to, touch **Navigate To** > **Go To**.
4. Follow the magenta line drawn between your current location and your destination. Navigate with caution; avoid land masses and obstacles while following the line to your destination.



Navigating Directly to a Destination

Marine Mode: Saving Your Current Location

To save a location, such as your marina or a good fishing spot, mark it as a waypoint.

1. From the Home screen, touch **Mark**.
2. If you want to name the waypoint, touch **Edit Waypoint** > **Name**. Use the on-screen keyboard to enter a name other than the number assigned to the waypoint by default.

Marine Mode: Navigating Directly to a Saved Location

1. From the Home screen, touch **Where To?** > **Waypoints**.
2. Touch the waypoint you want to navigate to.
3. Touch **Navigate To** > **Go To**.
4. Follow the magenta-highlighted line drawn between your current location and your destination. Navigate with caution; avoid land masses and obstacles while following the line to your destination.

Marine Mode: Using Man Overboard (MOB) Waypoints

Use a Man Overboard (MOB) waypoint to both create a waypoint with an international MOB symbol and immediately begin navigating to the MOB waypoint with a direct course.

To mark an MOB waypoint:

1. Touch **Mark** in the top-left corner of any screen except the Home screen. This immediately marks your current position as a waypoint.
2. Touch **Man Overboard**. This designates the waypoint as an MOB waypoint and begins navigation automatically.

NOTE: You can also touch **Man Overboard** on the Home screen to mark a MOB waypoint and immediately begin navigation.

Marine Mode: Stopping Navigation

1. While navigating, from the Navigation chart, touch **Menu**.
2. Touch **Stop Navigation**.

NOTE: You can also stop navigation from the Where To? screen.

Marine Mode: Adjusting the Backlight

1. From any screen, press and quickly release the **Power** key.
2. Touch and drag the backlight slider bar to the left to decrease the brightness, and drag it to the right to increase the brightness. The box to the right of the backlight slider bar shows the backlight level as a percentage.

NOTE: See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Please visit www.garmin.com for additional documentation and information.