garmin asus

nüvifone™ M20

owner's manual

© 2009 Garmin Ltd. or its subsidiaries and ASUSTeK Computer, Inc.

Garmin International, Inc.
1200 East 151st Street,
Olathe, Kansas 66062,
USA
Tel. (913) 397.8200 or
(800) 800.1020
Fax (913) 397.8282

Garmin (Europe) Ltd.
Liberty House
Hounsdown Business Park,
Southampton, Hampshire,
SO40 9LR UK
Tel. +44 (0) 870.8501241
(outside the UK)
0808 2380000 (within the UK)
Fax +44 (0) 870.8501251

Garmin Corporation
No. 68,
Jangshu 2nd Road,
Shijr, Taipei County,
Taiwan
Tel. 886/2.2642.9199
Fax 886/2.2642.9099

ASUSTeK Computer Inc.
15 Li-Te Road,
Peitou, Taipei,
Taiwan 11259
Tel. 886/2.2894.3447
Fax 886/2.2890.7698

All rights reserved. Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express prior written consent of Garmin and ASUS. Garmin and ASUS hereby grant permission to download a single copy of this manual onto a hard drive or other electronic storage medium to be viewed and to print one copy of this manual or of any revision hereto, provided that such electronic or printed copy of this manual must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited.

Information in this document is subject to change without notice. Garmin and ASUS reserve the right to change or improve their products and to make changes in the content without obligation to notify any person or organization of such changes or improvements. Visit www.garminasus.com for current updates and supplemental information concerning the use and operation of this and other Garmin-Asus products.

The combined Garmin-Asus logo is a trademark of Garmin Ltd. and ASUSTeK Computer, Inc.

Garmin® is a trademark of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Ciao!™, nüMaps Guarantee™, and nüvifone™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Microsoft, Excel, OneNote, Outlook, PowerPoint, ActiveSync, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin or ASUS is under license. Wi-Fi is a registered mark of the Wi-Fi Alliance. Panoramio is a trademark of Google Inc. OperaMobile is a trademark of Opera Software ASA.

September 2009 Part Number 190-01128-00 Rev. A Printed in China

Introduction

The nüvifone™ M20 is a multi-media mobile phone with integrated navigation and services.

Get Support

Go to www.garminasus.com for in-country support information.

Register Your Product

Register your product at www.garminasus.com to help us better support you. Keep the original sales receipt, or a photocopy, in a safe place.

Table of Contents

Introduction..... i
Get Support i
Register Your Product.....i

Get Started 1
nüvifone Device Features..... 1
Install the SIM Card and the Battery 2
Charge the Battery 3
Turn On Your nüvifone..... 3
Mount the nüvifone in Your Vehicle . 3

Get to Know Your nüvifone 5
Use the Home Screen 5
Use the Stylus 6
Scroll the Screen 6
Use the Navigation Key..... 6
Adjust the Volume..... 6
Open the Start Menu 7
Learn More 7
Lock Your nüvifone 7
Tips..... 7
About the LEDs 7
Status Bar Icons 8

Enter Data.....11
Use the Input Panel.....11
Write and Draw Your Notes 12
Record a Voice Note..... 12

Use the Phone..... 13
Open the Phone Application..... 13
Dial a Number..... 13
End a Call..... 13
Use In-Call Options 14
Receive a Call 15
Set Up Voicemail 15
Call Voicemail..... 15
Place a Conference Call..... 15
Place a Video Call 16
View Call History 17
Add a Contact 17
Call a Contact 17
Search for a Contact..... 18
Add a Contact to Favorites..... 18
Copy from Contacts to the SIM Card 18

Search for Locations..... 19
Find an Address..... 19
Set Your Home Location..... 19

Go! Page Options 20
Change the Search Area 21
Find a Point of Interest 21
Find Fuel Prices 22
Check Flight Status 22
Find Local Events 23
Find Movie Times 24
Find Parking 24
Find a Location Using Local Search .. 25
Find Panoramio™ Photos 25
Find Favorites 26
Find Recently-Found Locations 26
Find Cities 26
Find Intersections 27
Enter Coordinates 27
Send a Found Location 28
Navigate to an Appointment 29
Navigate to a Contact 29
Find Selected Text 29

Follow Your Route 30
See the Next Turn 31
View Details of the Route 31
About the Trip Computer 32
Save My Current Location 33
Take a Detour 33
Stop the Route 33
Edit the Active Route 33
Save the Active Route 33
Plan a Route 34
Edit or Delete a Saved Route 34
Navigate a Saved Route 34
Simulate a Route 35
Avoid a Road or Area 35
Edit Avoidances 35

Use the Navigation Tools 36
Browse the Map 36
Open the Where Am I? Page 36
Work with Favorites 37
Work with Tracks 37
Work with Map Sets 38

Ciao!™ 39
Register Your Device 39
Join Ciao! 39
Invite a Friend 40
Accept an Invitation 40
View My Details 40
About Friend Status 41
View Friends 41

View Invited Friends 41
Accept or Decline an Invitation 42
Hide Your Location 42
Remove a Friend 42
View Ciao! Networks 42
Disable Ciao! 42

Use Connected Services 43
About Connected Services 43
About Traffic 43
View Weather Data 45
Download Safety Cameras 45
Use the White Pages 46
View GeoNews 46

Send and Receive Messages 47
Send an SMS/Text Message 47
Send a Multimedia Message (MMS) . 47
Send a Location Message 48
Read Messages 48
Set Up an E-mail Account 49
Send an E-mail Message 50
Read an E-mail Message 50
Manually Send/Receive E-mail Messages 50
Synchronize E-mail Messages 50

Search the Internet 51
Use Internet Sharing 51

Read the News 52
Update News Articles 52
Read News Articles 52
Create a New Category 52
Add a Channel 53
Edit a Channel 53
Export Content 53

Play Music 54
Play a Song 54
Save a Song as a Ring Tone 55
Play a Playlist 55

View Pictures and Videos 56
View a Picture 56
View a Slideshow 57
Play a Video 57
Play a Video Stream 58

Use the Camera 59
Take a Picture 59
Record a Video 60

Organize Your Life 61

Use the Calendar 61
Open the Calendar 61
Use Tasks 62
Set the Clock and Alarms 63
Convert Currency 65
Microsoft® Office Mobile 66

Synchronize Your nüvifone .. 67
Install and Configure ActiveSync on Your Computer 67
Synchronize Using the USB Cable 68
Enable the USB Connection Mode Page 68
Synchronize with an Exchange Server 69
Synchronize Using Bluetooth® Technology 69
Backup and Restore Files 70
Search for Files 70

Get Connected 71
Manage Wireless Connections 71
Turn Off the Phone 71
Turn on Flight Mode 71
Set Up a Wi-Fi Connection 71
About Bluetooth 72
Exchange Files Using FTP 74

Customize Your nüvifone 75
Adjust the Backlight 75
Align the Screen 75
Orient the Screen 75
Change the Lock Settings 76
Change the Appearance 77
Customize the Call Settings 78
Configure Your Phone Network Profile 79
Use SMS Cell Broadcast 80
Adjust the Navigation Settings 80
Change Connected Services Settings 83
Change the GPS Settings 83
Change the Camera and Video Settings 84
View Device Information 87
View System Information 87
Restore the Default Settings 87

Appendix 88
nüMaps Guarantee™ 88
Additional Maps 88
Update the Software 88

Reset the nüvifone..... 88
Battery Information 88
Acquire GPS Satellite Signals 89
Change the Fuse in the Vehicle Power Cable 90
Mount on Your Dashboard..... 90
Specifications 91

Important Safety and Product Information..... 92

Troubleshooting Issues 99

Index 100

Get Started

See the *Important Safety and Product Information* on page 92 for product warnings and other important information.

Download the latest owner's manual at www.garminasus.com/nuvifoneM20.

nüvifone Device Features

Mini-USB connector for headphones, power, and computer connection

Stylus

Camera lens (on back)

Camera lens (not available on all devices)

Volume up and down keys

Navigation cradle power connector

Hold key; Slide down to lock the screen.

Send key

5-Way Navigation key

End/Power key

Install the SIM Card and the Battery

WARNING: This product contains a lithium-ion battery. To prevent damage, remove the device from the vehicle when exiting or store it out of direct sunlight.

1. Slide the battery cover off the back of the nüvifone.

2. Insert the Subscriber Identity Module (SIM) card in the slot at the top of the battery compartment. Insert the notched corner of the SIM card first with the gold contacts facing down.

3. Locate the lithium-ion battery that came in the product box.
4. Locate the metal contacts on the end of the lithium-ion battery.
5. Insert the battery so that the metal contacts on the battery match up with the metal contacts inside the battery compartment.

6. Slide the battery cover onto the back of the nüvifone.

Charge the Battery

Charge the battery for up to four hours before using for the first time. If you completely discharge the battery, recharge it for at least 20 minutes before turning on your nüvifone.

1. Insert the plug into the AC power adapter, if necessary.
2. Plug the USB cable into the AC adapter.
3. Connect the mini-USB end of the USB cable to the mini-USB connector on the bottom of your nüvifone.
4. Plug in the AC adapter into a power outlet.

You can also charge the nüvifone using the USB cable and your computer.

Turn On Your nüvifone

Press and hold the **Power** key to turn on and turn off the nüvifone.

Mount the nüvifone in Your Vehicle

Before mounting the nüvifone, see page 97 for information about laws pertaining to windshield mounting.

1. Plug the vehicle power cable into the power connector on the back of the cradle.

2. Remove the clear plastic from the suction cup. Clean and dry your windshield and the suction cup with a lint-free cloth.
3. Place the suction cup on the windshield.

4. Flip the lever back, toward the windshield.

5. Snap the cradle onto the suction cup arm.
6. Fit the gold contacts on the left side of your nüvifone into the cradle.
7. Tilt the nüvifone back until it snaps into the cradle.

8. Plug the other end of the vehicle power cable into a power outlet in your vehicle.

Remove the nüvifone from the Cradle

1. Press up on the tab on the top of the cradle.
2. Tilt the nüvifone forward.

Remove the Cradle from the Mount

1. Turn the cradle to the right or left.
2. Apply pressure until the socket on the cradle releases the ball on the mount.

Remove the Suction Cup Mount from the Windshield

1. Flip the lever on the suction cup mount toward you.
2. Pull the tab on the suction cup toward you.

Get to Know Your nüvifone

Use the Home Screen

The Home screen appears when you turn on your device. If you are not currently in a call, you can press the **End** key or tap > **Today** to return to the Home screen.

Tap to open the Start menu.

Status bar. Tap an icon to view more information.

Application shortcut icons. Tap an icon to open the application.

Current date and time. Tap to set the clock and alarms.

To view more icons, touch and drag your finger between the two rows of icons.

Tap to place a phone call.

Tap to find and navigate to a location.

Tap to open the map.

Use the Stylus

The stylus is a pen-like device. To remove the stylus, pull it out of the lower-right corner on the back of your nüvifone.

- Use the stylus to write, draw, select, or drag an item on the screen.
- Single-tap an item to select or open it.
- Tap and hold an item to see a menu.

Scroll the Screen

- Touch and drag your finger to slowly scroll the screen.
- Touch, drag, and quickly remove your finger to continue scrolling the menu after removing your finger.
- Tap the screen to stop scrolling.

Use the Navigation Key

Press the **Navigation** key in any direction to move the cursor in that direction. Press the center of the key to select an item.

Adjust the Volume

1. Tap on the status bar.
2. Adjust the volume:
   - Drag the slider to adjust the device and phone volume.
   - Tap to turn off the volume and turn on the Vibrate feature.
   - Tap to turn off the volume.

You can also press the **Volume** keys on the left side of the device to adjust the volume.

Open the Start Menu

Tap to open the Start menu, which provides access to the programs, settings, and the Help file.

Learn More

1. Tap > **Help**.
2. Tap **Search** and enter a search term.
3. Tap a topic.

Lock Your nüvifone

You can lock the touchscreen on your nüvifone to prevent accidental taps.

1. With the nüvifone turned on, slide down the **Hold** key on the right side of the nüvifone.
2. Slide up the **Hold** key to unlock your nüvifone.

To lock your phone automatically after a period of inactivity, see page 76.

Tips

- Tap to access the menu for a particular page.
- Tap and to see more choices.
- Tap to return to the previous page.

About the LEDs

Red Blinking—battery is low.

Red Constant On—battery is being charged.

Green Constant On—battery is fully charged.

Green Blinking—network is detected.

Blue Blinking—Bluetooth® or Wi-Fi® technology is enabled.

Status Bar Icons

The icons along the top of the screen indicate the status of various system items. Some icons you can tap to access more information.

Type	Icon	Description
Call status		Call in progress
		Call forwarded
		Call on hold
		Missed call
General Packet Radio Service (GPRS) connection status* * This icon depends on your location and mobile service provider.		GPRS available
		Connecting via GPRS
		Connected via GPRS
		3rd Generation (3G) service available
		HSPA available
		EDGE available

Messaging status		New messages
		Multiple messages; tap the icon to view all messages.
Battery status		Battery fully charged
		Battery partially charged
		Battery charging
		Battery low
Signal status		No cellular phone service
		No signal
		Number of bars indicate signal strength
		Phone off
ActiveSync® connection status		ActiveSync synchronization in progress
		Connecting with ActiveSync
		ActiveSync connection not active
		Synchronization error

Sound status		Sound on
		Sound off
Wi-Fi® status		Wi-Fi is available
		Wi-Fi connected
Bluetooth technology headset connection		Bluetooth stereo headset connected
Roaming service		Roaming service. This icon appears if you have the international roaming feature.
Mode status		Vibrate or Meeting mode on
Speakerphone status		Speakerphone on
Alarm status		Alarm is set
SIM card status		No SIM card installed
Location Search		Tap to find information about this location.
GPS status		GPS searching
		GPS off

Enter Data

Use the Input Panel

When you start an application or tap a field that requires you to input data, the Input Panel icon appears.

Note: Not all input methods are available in all languages.

Select a Different Input Method

Not all methods are available in all regions.

1. Tap to open the Input Panel options.
2. Tap an input method.
3. Tap .

Use the On-screen Keyboard

1. Tap to open the Input Panel.
2. Tap the keys on the on-screen keyboard to enter.
3. Tap to close the keyboard.

Adjust the Word Completion Settings

You can adjust the automatic word completion (predictive text) settings

1. Tap > **Settings** > **Personal** > **Input**.
2. Tap the **Word Completion** tab, and adjust the settings.

Use the Block Recognizer

The Block Recognizer allows you to use a single stroke to write letters, numbers, symbols, or punctuation, which are converted into typed text.

Write letters in the left side of the box. Write numbers in the right side of the box.

Use the Letter Recognizer

The Letter Recognizer allows to you write individual letters, numbers, or special characters, which are converted into typed text.

Write capital letters in the left side of the box. Write lower case letters in the middle. Write numbers in the right side of the box.

Use the Transcriber

Transcriber is a handwriting recognition program that also recognizes numbers and symbols. Transcriber is not available in all languages.

Tap the screen where you want the text to appear. Use the stylus to write legibly on the screen. The handwriting is converted to text after you lift the stylus from the screen.

Write and Draw Your Notes

1. Tap > **Notes** > **New** > **Menu**.
2. Tap **Draw**.
3. Write or draw on the screen.
4. Tap **OK** to save the note.

Set the Default Input Mode for Notes

1. Tap > **Notes** > **Menu** > **Options**.
2. Tap **Writing** for the Default mode.
3. Tap **OK** when finished.

Record a Voice Note

1. Tap > **Notes**.
2. Tap **New** or tap a saved note to open it.
3. Tap **Menu** > **View Recording Toolbar**, if necessary.
4. Tap to begin recording.
5. Place the receiver near your mouth or source of sound.
6. Tap when finished recording.
7. Tap to play the voice recording.
8. Tap **OK** to save the note.

Use the Phone

Open the Phone Application

Use one of the following methods to open the phone application:

- Press the **Send** key.
- From the Home screen, tap **Call**.

Dial a Number

1. Press the **Send** key.
2. Tap to open the keypad.

3. Dial the number.

   Note: Tap and hold ***** to enter a **,** (comma) and **0** to enter a **+** (plus sign).

4. As you dial, a list appears showing similar numbers you have dialed.
   - Tap to view the entire list.
   - Tap a number in the list to select the number.
   - Tap to return to the keypad.
5. Press the **Send** key.

End a Call

To end a call, press the **End** key.

Use In-Call Options



While you are in a call, the following options appear:

Speaker—activate the speakerphone.

Mute—mute the audio input.

Hold—place the current call on hold.

Swap—change between the current call and the call on hold, if you are on call waiting.

Note—write a note related to this call. You can view the note by tapping the call in your call history.

Contacts—view your contacts.

History—view your call history.

—view the following options:

- **Turn Hands-free Off**—turn off the hands-free function, if available.
- **Conference**—start a conference call, if you have a call on hold and another call active.

The phone hides these options if you are in a call and do not interact with the phone for 4 seconds. To show the options again, press the **Send** key or the **Navigation** key.

Receive a Call

Tap **Answer** to answer the call.

Tap **Ignore** to reject the call or send the call to voicemail, if voicemail is set up.

If you answer a call while you are already on another call, the original call is placed on hold.

Set Up Voicemail

1. Tap > **Settings** > **Personal** > **Phone** > **Services** tab.
2. Tap **Voicemail and Text Messages** > **Get Settings**.
3. Verify that your voicemail number is correct, and tap **OK**.

Call Voicemail

1. Press the **Send** key.
2. Tap .
3. Tap and hold **1**.

Place a Conference Call

NOTE: Not all mobile phone networks support conference call. Contact your service provider for details.

1. Place a call to the first phone number.
2. Tap **Hold**.
3. Tap , and place a call to the second phone number.
4. Tap > **Conference**.

To view the other members of the conference call, tap **More**.

If you receive a call while you are already on another call, you can start a conference call by tapping > **Conference**.

Speak Privately During a Conference Call

You can speak privately with another member of the conference call.

1. During the conference call, tap **More** > **Private**.
2. Tap a phone number. The other members of the conference call can continue to speak to each other.
3. To end the private conversation, tap > **Conference**.

Place a Video Call

Video calling is not available on all nüvifone devices.

1. Place a call.
2. Tap .
3. Use the following options during the call:

   —interchange the images on your screen.

   —hide your image from the other person on the call.

   —change from your primary camera to a second camera, if one is available. If you activate a second camera, a zoom option appears.

When you are on a video call, incoming calls are automatically sent to voicemail.

View Call History

1. Press the **Send** key.
2. Tap , if necessary.
3. Tap a number or a contact in the list to view your call history for that number or contact.
4. If a call in the list is marked with , tap the call to view the notes associated with that call.
5. Select an option:
   - Tap **Call** or press the **Send** key to place a call.
   - Tap **Video Call** to place a video call.
   - Tap **More** to view contact information, if available.
   - Tap > **Save to Contacts** to save the phone number as a contact.
   - Tap > **Delete** to delete this call history.

Clear Your Call History

1. Press the **Send** key.
2. Tap .
3. Tap > **Clear All**.

Add a Contact

1. Press the **Send** key.
2. Tap > > **New Contact**.
3. Enter the information for the contact. Tap **Done** when finished.
4. Tap **More** to add additional information, if necessary. Tap **OK** when finished.
5. Tap to save the contact.

Call a Contact

1. Press the **Send** key.
2. Tap .
3. Tap a contact.
4. Tap **Call**.

Search for a Contact

1. Press the **Send** key.
2. Tap > .
3. Enter the contact name, and tap **Done**.
4. Tap **More** to search your company directory or the white pages.

Search Your Company Directory

You can search your company directory, if available. You must first set up the device to use your company's Microsoft Exchange Server. An active Internet connection is required.

Search the White Pages

You can search the regional white pages. White pages are not available in all areas. An active Internet connection is required.

Add a Contact to Favorites

You can include up to 30 contacts in favorites.

1. Press the **Send** key.
2. Tap > .
3. Tap the contact you want to add.

Copy from Contacts to the SIM Card

1. Tap > **SIM Manager** > **Menu** > **Retrieve from Contacts**.
2. Select the Contacts to copy.
3. Tap **Retrieve**.

You cannot retrieve the phone Contacts when the SIM card is full.

Search for Locations

The Search menu provides several different categories you can use to search for locations.

Find an Address

NOTE: Depending on the version of the built-in map data on your device, the button names and order of steps could be different than the steps below.

1. Tap **Search** > **Address**.
2. If necessary, select the state, country, or province.
3. To search all cities, tap **Search All Cities**. You can also tap **Spell City**, enter all or part of the name, and then tap the city in the list.
4. Enter all or part of the street name or number and then tap the street in the list.
5. Enter the house number and then tap **Done**.
6. Tap the correct address in the list.

Set Your Home Location

You can save a favorite called "Home" and quickly generate a route to it.

1. Tap **Search** > **Home**.
2. Tap **Enter My Address** or **Use Current Location**.

Go Home

After you have saved your home location, you can create a route to it.

Tap **Search** > **Home**.

Go! Page Options

After you find a location, an information page appears, displaying the address and the phone number (if known) of the location.



Call—dial the phone number of the location, if available.

Map—view the location on the map.

Go!—create a route to the location.

Tap for the following options:

- **Save to Favorites**—save the location to Favorites, which is a collection of your favorite locations.
- **Send Location**—send the location to other users as a location message.
- **Find Nearby**—search for other locations near this one.
- **Connected Services**—view connected services for the location.

Change the Search Area

By default, your nüvifone finds locations near your current location.

Find a Location Near Your Route

1. Tap **Search**.
2. Tap > **Near**.
3. Tap the appropriate option, and then tap **Done**.

Find a Location Near a Different City

1. Tap **Search**.
2. Tap > **Near**.
3. Tap **Near Other**.
4. Tap **Spell City** or **Browse Map**.
5. Find the location, and then tap **Done**.

Find a Point of Interest

The detailed maps loaded in your nüvifone contain millions of points of interest, such as restaurants, hotels, and auto services.

Find by Category

1. Tap **Search** > **Points of Interest**.
2. Tap a category.
3. Tap a subcategory or tap **All Categories**. A list of items near your current location appears.
4. Tap the item you want.

Find by Spelling the Name

1. Tap **Search** > **Points of Interest**.
2. Tap **Spell Name**, enter all or part of the name, and tap **Done**.
3. Tap the item you want.

Find Fuel Prices

This service is available as a paid Connected Services subscription. Fuel prices are not available in all areas. A data connection is required for this feature.

1. Tap **Search** > **Points of Interest** > **Fuel** > **Fuel Prices**.
2. Tap a fuel type. A list of fuel prices near your current location appears.
3. To sort the list by lowest price, tap **Sort**. To sort by distance, tap **Sort** again.
4. Tap an item in the list.

TIP: You can also find fuel prices under **Connected Services** > **Fuel Prices**.

Check Flight Status

Flight status information may not be available in all areas. A data connection is required for this feature.

1. Tap **Search** > **Points of Interest** > **Transportation** > **Flight Status**.
2. To view flight information from an airport near another city, tap > **Near**.
3. Tap an airport in the list.
4. Select an option to find a flight:
   - **Check Flight Number**—enter a flight number, and then tap **OK**. Tap a flight in the list.
   - **Departures**—tap **Select Using Destination City**, **Select Using Airport Code**, or **View All Departures**. Enter the appropriate data, and then tap a flight in the list.

- **Arrivals**—tap an airline, and then tap a flight in the list.

5. If your flight has multiple connections, tap > **Next Leg**, and then tap the next flight.

Find Local Events

You can search for upcoming events, including art shows, musical performances, and sporting events.

This service is available as a paid Connected Services subscription. Local events are not available in all areas. A data connection is required for this feature.

1. Tap **Search** > **Points of Interest** > **Entertainment** > **Local Events**.
2. Tap a category.
3. Tap the arrows or the date to select a different date, if necessary.
4. Tap an event to view more information.
5. To add the event as an appointment on your calendar, tap **Remind Me!**. If the event begins within two hours of the current time, you can tap **Go!** to navigate to the event.

TIP: You can also find local events prices under **Connected Services** > **Local Events**.

Find Movie Times

This service is available as a paid Connected Services subscription. Movie times are not available in all areas. A data connection is required for this feature.

1. Tap **Search** > **Points of Interest** > **Entertainment** > **Movie Times**.
2. Tap the arrows or the date to select a different date, if necessary.
3. Tap **Find by Movie Title** or **Find by Movie Theater**.
4. Tap a movie title and a theatre.
5. To add a show time as an appointment on your calendar, tap > **Remind Me!**, and tap a show time.

   If the movie begins within two hours of the current time, you can tap **Go!** to create a route.

TIP: You can also find movie times under **Connected Services** > **Movie Times**.

Find Parking

This service is available as a paid Connected Services subscription. Parking is not available in all areas. A data connection is required for this feature.

1. Tap **Search** > **Points of Interest** > **Auto Services** > **Connected Parking**.
2. Tap a location in the list to view more information.

TIP: You can also find up-to-date parking information under **Connected Services** > **Parking**.

Find a Location Using Local Search

Local search enables you to search for the most current location information.

Local Search is not available in all areas. A data connection is required for this feature.

TIP: You can also search using Local Search under **Connected Services** > **Local Search**.

Spell a Location Name or Category

In addition to searching by spelling the name of a location, you can also spell the names of categories, like "salon" or "coffee."

1. Tap **Search** > **Local Search**.
2. Tap **Spell Name**, enter your search term, and tap **Search**.
3. Tap the item you want.

Search by Category

1. Tap **Search** > **Points of Interest** > **Local Search**.
2. Tap a category, and then tap a subcategory.
3. Tap the item you want.

Find Panoramio™ Photos

Panoramio photographs contain special information about the location where the photograph was taken. You can use this information to navigate to locations and landmarks shown in Panoramio photographs.

Panoramio photographs are not available in all areas. A data connection is required for this feature.

1. Tap **Search** > **Panoramio Photos**.

2. A list of photographs from nearby locations appears. To find photographs near a different location, tap > **Near**, and select a location.
3. Tap a photograph in the list.

Find Favorites

1. Tap **Search** > **Favorites**.
2. To search by name, tap **Spell**, enter all or part of the name.
3. Tap the favorite you want.

Find Recently-Found Locations

The nüvifone stores the last 40 locations you have found.

1. Tap **Search** > **Recent Finds**.
2. Tap the item you want.

Find Cities

1. Tap **Search** > **Cities**. A list of cities near your current location appears.
2. To search by name, tap the edit box along the top of the screen, enter the name, and then tap **Done**.
3. Tap a city.

Find Intersections

1. Tap **Search** > **Intersection**.
2. If necessary, select the state, country, or province.
3. To search all cities, tap **Search All Cities**. You can also tap **Spell City**, enter all or part of the name, and then tap the city.
4. Enter all or part of the first street name or number and then tap the street.
5. Enter all or part of the second street name or number and then tap the street.
6. Tap the correct intersection in the list.

Enter Coordinates

If you know the geographic coordinates of your destination, you can use your nüvifone to navigate there. This can be especially helpful when geocaching.

1. Tap **Search** > **Coordinates**.
2. Enter the coordinates, and tap **Next**.

Send a Found Location

You can find a location and send it to people using messaging or e-mail.

1. Find a location.
2. On the Go! page, tap > **Send Location**.
3. Tap a contact.
4. Tap an account.
5. To attach a map of your location, tap **Yes**.
   - Use the map tools to adjust the map scale or to pan to a different location.
   - Tap > **Preview** to view the map, and then tap **OK**.
6. To edit the message, tap .
7. Tap **Send**.

Navigate to an Appointment

You can create a route to an appointment in your calendar.

1. From your calendar, tap an appointment.
2. Tap **Menu** > **Location Info**.
3. Select an option to find the appointment location.
3. Tap the location.
4. Tap **Go!**.

Navigate to a Contact

1. Press the **Send** key.
2. Tap .
3. Select a contact.
4. Tap **Go!**.

Find Selected Text

You can find location information for selected text in an SMS message, in an e-mail, or in your Web browser.

1. Drag to select the text.
2. Tap .
3. Select an option:
   - **Address**—search for the item by address.
   - **Local Search**—search for the location on the Internet.
4. Tap an item in the list.

Follow Your Route

After you select a location and tap **Go!**, your nüvifone creates a route to the location. Your route is marked with a magenta line.

If you depart from the original route, your nüvifone recalculates the route and provides new directions.

A speed limit icon may appear as you travel on major roadways. This icon displays the current speed limit of the roadway.



1. Tap to view the next turn.
2. Tap to view the route details.
3. Tap to view the Traffic menu.
4. Tap to zoom in and zoom out.
5. Tap to browse the map.
6. Tap to view the trip computer.
7. Tap to return to the Home screen.
8. Tap to view the Where Am I? page.

See the Next Turn

When you are navigating a route, you can view the turn on the map and the distance and time left before you reach the turn.

1. While navigating to a destination, tap the turn bubble on the map, or tap any turn in the turn list.
2. Tap the arrows to see more turns in the route.

View Details of the Route

When you are navigating a route, you can view all of the turns for your entire route and the distance between turns.

1. While navigating to a destination, tap the text bar on the top of the map.
2. Tap a turn in the list to view the turn on a map.
3. Tap to edit the route.

About the Trip Computer

The trip computer displays your current speed and provides helpful statistics about your trip.

If you make frequent stops, leave your nüvifone turned on so it can accurately measure elapsed time during the trip.

Open the Trip Computer

Use one of the following methods to open the trip computer:

- Tap **Speed** on the map.
- Tap > **Tools** > **Trip Computer**.

Reset the Trip Computer

Reset the trip computer before beginning a trip.

1. Tap > **Tools** > **Trip Computer**.
2. Tap .
3. Select an item to reset.

Save My Current Location

1. Tap **View Map**.
2. Tap the lower-right data field.
3. Tap > **Save**.

Take a Detour

1. While navigating a route, tap .
2. Tap **Detour**.

The nüvifone attempts to get you back on your original route as quickly as possible. If the route you are currently taking is the only reasonable option, the nüvifone might not calculate a detour.

Stop the Route

1. While navigating a route, tap .
2. Tap **Stop**.

Edit the Active Route

1. While navigating a route, tap the text bar on top of map.
2. Tap > **Edit**.
3. Tap **Add Start Point** or **Add End Point**.
4. Select a method to select a via point.
5. Tap **Done** when finished.

You can also add via points to a route using the Find feature. Find an item, and then tap **Go!**. When prompted to add the point as a via point to the current route, tap **Yes**.

Save the Active Route

You can save the route you are currently navigating and use it again later.

1. Return to the Home screen.
2. Tap **Tools** > **Manage My Data** > **Routes**.

3. Tap **Save Active Route**.
4. Tap **OK**.

Plan a Route

1. Tap **Tools** > **Manage My Data** > **Routes**.
2. Tap **Create New Custom Route**.
3. Select a starting point.
4. Select a final destination.
5. Add via points as necessary, or tap **None**.
6. Tap your route calculation preference.
7. Tap > **Save** to save the route, or tap **Go!** to save and navigate the route.

Edit or Delete a Saved Route

1. Tap **Tools** > **Manage My Data** > **Routes**.
2. Tap **View Routes**.
3. Tap a route, and then tap > **Edit**.
4. Delete the route or make changes as needed.

Navigate a Saved Route

1. Tap **Tools** > **Manage My Data** > **Routes**.
2. Tap **View Routes**.
3. Tap the route you want to navigate.
4. Tap **Go!**.

Simulate a Route

If the GPS is off, you can simulate driving a route.

1. Tap > **Settings** > **Navigation** > **GPS** > **GPS Status.**
2. Tap > **Disable GPS**.
3. Find a destination and tap **Go!**.
4. Tap **Tools** > **Simulate Route**.

Avoid a Road or Area

1. Tap > **Settings** > **Navigation** > **Routing** > **Avoidance Setup** > > **Custom** > **Add New Road or Add New Area**.
2. Select the road or area you want to avoid, and tap **Next**.
3. Tap **OK** to save the avoidance.

Edit Avoidances

1. Tap > **Settings** > **Navigation** > **Routing** > **Avoidance Setup** > > **Custom** > **View List**.
2. Tap the avoidance you want to edit.
3. Select an option.

Deactivate Avoidances

1. Tap > **Settings** > **Navigation** > **Routing** > **Avoidance Setup**.
2. Clear the avoidance check box.

Use the Navigation Tools

Browse the Map

1. Use one of the following methods to open the Browse Map:
   - Tap > **Tools** > **Browse Map**.
   - Tap **View Map**, and then tap the vehicle icon.
2. Drag to move the map.
3. Tap **+** to zoom in. Tap **-** to zoom out.
4. Tap a location on the map, and then tap for more options.

Open the Where Am I? Page

The **Where Am I?** page displays information about your current location. This is a helpful feature if you need to tell emergency personnel your location.

1. Use one of the following methods to open the Where Am I? page:
   - Tap > **Tools** > **Where Am I?**.
   - Tap **View Map**, and then tap the lower-right corner data field.
2. Tap a button to view the nearest locations in that category.

   Tap > **Save** to save your current location.

Work with Favorites

Save a Location as a Favorite

1. Find the item you want to mark as a favorite.
2. On the Go! page, tap > **Save to Favorites**.

Edit Favorites

1. Tap > **Tools** > **Manage My Data** > **Favorites**.
2. Tap a favorite, and then select an option.
3. Make changes as needed.

Work with Tracks

Record a Track

You can record the path you travel (called a "track") and view it as a dotted line on the map.

1. Tap > **Tools** > **Manage My Data** > **Tracks**.
2. Tap **Options**.
3. Tap **Recording Interval**, and then select how often you want track points recorded. **More Often** records more points and creates more-detailed tracks, but fills up track memory more quickly.

4. Tap **Show Active Track on Map**.
5. Tap **Enabled** to view the active track on the map while it is being recorded.

After you record tracks, you can save them and view them on the map.

Save a Track

1. Tap > **Tools** > **Manage My Data** > **Tracks**.
2. Tap **Save Active Track**.
3. Tap **Save**.

After you save a track, it is recommended that you clear the track memory by tapping **Clear Active Track**.

Saved tracks appear on the map automatically.

View and Edit a Saved Track

1. Tap > **Tools** > **Manage My Data** > **Tracks**.
2. Tap **View Saved Tracks**.
3. Tap a track.
4. To view the track on the map, tap > **Map**.
5. To edit the track, tap > **Edit**, and then select an option.

Work with Map Sets

Your phone includes built-in map data. You can also purchase additional map data from your Garmin or ASUS dealer.

To view the map sets loaded on your phone, tap > **Tools** > **Manage My Data** > **Map Sets**.

Ciao!™

Ciao! periodically sends your location to our partner networks and downloads the most recent location of your friends. This application only submits your location when you tell it to, unless you enable automatic updates. Ciao! is not available in all areas.

A data connection is required for this feature.

Register Your Device

Before you join Ciao! for the first time, you must first register your device.

1. Tap **Ciao!**.
2. Read and accept the on-screen messages.
3. Tap **Register**. The Web browser launches.
4. Follow the steps to register your device. After registering, you will receive an SMS message for verification.
5. Open the SMS message, and tap the link to complete the verification process.

You are now ready to join Ciao!.

Join Ciao!

After you register your device, you can join Ciao!.

1. Tap **Ciao!**.
2. Read and accept the registration information.
3. Tap a type of location update, **Manual** or **Automatic**.
4. Enter a display name.
5. Tap **Complete**. Your location is updated and becomes available in the network.

Invite a Friend

1. Tap **Ciao!** > **Invite**.
2. Tap an option to enter a phone number.
3. Tap the button under **Friend's Country**, and select a country.
4. Tap **Send Invite**.
5. Select the network your friend is using. If your friend is using Ciao!, you can select any network in the list. Tap **OK**.

Accept an Invitation

When you receive an invitation, a message appears on the screen.

1. Select the invitation in your list of friends.
2. Tap **Accept**.
3. Tap **Yes** to allow the friend to view your location. The location information for the friend appears.
4. Tap **Go!** to create a route to the friend, or tap **Map** to view the friend on the map.

After you accept an invitation from a friend, he or she becomes a "trusted" friend, and you can view location information for each other.

View My Details

1. Tap **Ciao!** > **My Details**.
2. To update your current location information, tap **Send Update**.
3. To change your status message, tap **Change Status**, and enter a new status message.
4. Tap for the following options:
   - **Change Name**
   - **Change Updates**—tap **Auto** to update your location information automatically at regular intervals, or tap **Manual** to update your position only when you tap **Send Update**.

About Friend Status

Trusted—if the list shows the distance and direction to the friend, that friend is "trusted." The friend has accepted an invitation from you, or you have accepted an invitation from the friend.

Invited—you have invited the friend, but he or she has not accepted or declined the invitation.

Pending—the friend has invited you, but you have not accepted or declined the invitation.

View Friends

1. Tap **Ciao!**.
2. Tap a friend in the list. The location information for the friend appears.
3. Tap **Go!** to create a route to the friend, or tap **Map** to view the friend's location on the map.

To view all of your friends on the map, tap **Ciao!** > > **View Map**.

View Invited Friends

1. Tap **Ciao!**.
2. Tap an Invited friend in the list.
3. To remove the invitation, tap **Remove Invitation**.

Accept or Decline an Invitation

1. Tap **Ciao!**.
2. Tap a Pending friend in the list.
3. Tap **Accept** or **Decline**.

Hide Your Location

Tap **Ciao!** > > **Hide**. Your current location is hidden from your friends.

To stop hiding, tap **Ciao!** > > **Stop Hiding**.

Remove a Friend

1. Tap **Ciao!**.
2. Tap a friend in the list, and tap > **Remove**.
3. Tap **Yes**.

View Ciao! Networks

1. Tap **Ciao!** > > **Privacy**.
2. Tap > **Networks**.
3. Tap a hyperlink to view a network Web site in the Web browser.

Disable Ciao!

1. Tap **Ciao!** > > **Privacy**.
2. Tap > **Disable Ciao!**.

All the Ciao! information stored on your device is removed. You no longer send any position updates.

To enable Ciao!, you must join Ciao! again.

Use Connected Services

About Connected Services

Use Connected Services to search for location-relevant information such as live weather data, flight status, and Panoramio photos. You can also access local search using the Internet.

Not all services are available in all areas. Additional services are available with a subscription. For more information, go to www.garminasus.com.

Your phone must have a data connection to access Connected Services. Your regular Internet and data transfer charges apply.

Your Connected Services account is activated automatically on most phones. If you need to activate your account manually, or to activate additional services, go to www.garminasus.com.

About Traffic

Traffic information and delay time are not available in all areas. This service is available as a paid Connected Services subscription. A data connection is required for this feature.

NOTE: Garmin and ASUS are not responsible for the accuracy of the traffic information.

About the Traffic Icon

When you are receiving traffic information, a traffic icon appears in the upper-left corner of the Map page. The traffic icon changes color to indicate the severity of traffic conditions on your route or the road you are currently travelling.

Green—traffic is flowing freely.

Yellow—moderate traffic congestion.

Red—very slow or stop-and-go traffic.

Traffic on Your Route

When calculating your route, the nüvifone examines the current traffic and automatically optimizes the route for the shortest time. If a severe traffic delay occurs on your route while you are navigating, the nüvifone automatically recalculates the route. You might still be routed through traffic if no better alternative routes exist.

If a non-severe traffic delay occurs on your route, the traffic icon shows how much time the delay has added to your route. This time is already included in your estimated arrival time.

Manually Avoid Traffic on Your Route

1. On the Map page, tap the traffic icon.
2. Tap **Traffic On Route**.
3. Tap **Avoid**.

You might still be routed through traffic if no better alternative routes exist.

View the Traffic Map

The traffic map shows color-coded traffic flow and delays on nearby roads.

1. On the Map page, tap the traffic icon.
2. Tap **Show Traffic Map**.

To return to the normal map, tap the traffic icon, and then tap **Show Normal Map**.

View Traffic Delays

1. On the Map page, tap the traffic icon.
2. Tap **Traffic Search** to view a list of traffic delays.
3. Tap an item in the list to view the delay on a map and details about the delay. If there is more than one delay, tap the arrows to view the additional delays.

View Weather Data

A data connection is required for this feature.

1. Tap **Weather**. Weather data for your current location appears.
2. To view details, tap an item in the list.
3. To show weather for a different location, tap > **New City**, and then select an option.

Download Safety Cameras

This service is available as a paid Connected Services subscription. A data connection is required for this feature. Data not available for all areas.

CAUTION: Garmin and ASUS are not responsible for the accuracy of, or the consequences of using, a custom point of interest (POI) or a safety camera database.

1. Tap **Connected Services** > **Safety Cameras**.
2. Tap a region or regions in the list, and then tap **Done**.

Use the White Pages

This service is available as a paid Connected Services subscription. A data connection is required for this feature.

Find by Name in White Pages

1. Tap **Connected Services** > **White Pages** > **By Name**.
2. Enter the last name, and tap **Done**.
3. Enter the first name (optional), and tap **Done**.
4. Enter the postal code, if necessary.
5. To search near a different location, tap **Near**, and tap a location.
6. To re-enter the name, tap **Retry**.

Find by Phone Number in White Pages

1. Tap **Connected Services** > **White Pages** > **By Phone Number**.
2. Enter the area code and phone number, and tap **OK**.

View GeoNews

This service is available as a paid Connected Services subscription. A data connection is required for this feature. This service is only available in some areas.

1. Tap **Connected Services** > **GeoNews**.
2. To select a different location, tap > **GeoNews Near**, and select a location.
3. Tap a news service.
4. Tap an item in the list to view details.

Send and Receive Messages

Your regular messaging fees apply when sending and receiving messages.

Send an SMS/Text Message

1. From the Home screen, tap **Text**.
2. Tap **Menu** > **New** > **Text Message**.
3. Enter a recipient, or tap **Menu** > **Add Recipient** to select from your Contacts list.
4. Enter the text message.
5. Tap **Send**.

Send a Multimedia Message (MMS)

1. From the Home screen, tap **Text**.
2. Tap **Menu** > **New** > **Multimedia Message**.
3. Tap **Select**.
3. Enter a recipient, or tap **Menu** > **Add Recipient** to select from your Contacts list.
5. Tap below the subject line to attach an image or video.
6. Tap **Insert Text** to enter the text of the message.
7. Tap **Insert Audio** to attach an audio file.
8. Tap **Send**.

Send a Location Message

Location messages allow you to send your current location information to other people.

CAUTION: Use caution when sharing your location information with others.

1. Create a message, and then tap **Menu** > **Location Info**.
2. Follow the instructions on the screen.
3. To attach a map of your location, tap **Yes**.
   - Use the map tools to adjust the map scale or to pan to a different location.
   - Tap **Preview** to view the map, and then tap **OK**.
4. To edit the message, tap .
5. Tap **Send**.

NOTE: Sending a map image requires MMS picture messaging support on the phones of both the sender and the receiver.

You can also send location messages when you view a contact, when you finish a phone call, or when you find a location.

Read Messages

As you receive messages, the message and e-mail icons on the Home screen display the number of unread messages.

1. Tap **Text**. Unread messages are displayed in bold.
2. Tap a message to read it.

Reply to a Message

1. Tap **Text**.
2. Tap a message, and then tap **Menu** > **Reply/Forward** > **Reply** or **Reply All**.

Forward a Message

1. Tap **Text**.
2. Tap a message, and then tap **Menu** > **Reply/Forward** > **Forward**.
3. Enter the addresses to which you want to forward the message.

Delete Messages

1. Tap **Text**.
2. Tap a message, and then tap **Menu** > **Delete**. The message is moved to the Deleted Item folder.

To recover a deleted message, move the message back from the Deleted Item folder.

To empty the Deleted Item folder, tap **Menu** > **Tools** > **Empty Deleted Items**.

If a message is deleted from the Deleted Item folder, it cannot be recovered.

Set Up an E-mail Account

Your nüvifone can automatically configure account information for some e-mail accounts.

If additional information is required, see your e-mail account provider.

1. Tap **E-mail**.
2. Enter your e-mail address and password.
3. Tap **Next** to obtain your e-mail settings from the Internet.
4. Follow the on-screen instructions to set up your e-mail account on your device.

Send an E-mail Message

1. Tap **E-mail**.
2. Tap an e-mail account.
3. Tap **Menu** > **New**.
4. Enter an e-mail address in the To field, or tap **Menu** > **Add Recipient** to select from your Contacts list. If you are sending a message to more than one recipient, separate the e-mail addresses with a semicolon (;).
5. Enter your message in the message field.
6. When finished, tap **Send**.

If you are working offline, e-mail messages are saved to the Outbox folder and sent the next time you connect.

Read an E-mail Message

1. Tap **E-mail**.
2. Tap an e-mail account, if necessary.
3. Tap an e-mail message to view it.

Manually Send/Receive E-mail Messages

1. Tap **E-mail**.
2. Tap an e-mail account.
3. Tap **Menu** > **Send/Receive**.
4. To stop this process, tap **Menu** > **Stop Send/Receive**.

Synchronize E-mail Messages

You can include e-mail messages as part of the general synchronization process. See page 67. To connect directly to an e-mail server, see the ActiveSync Help file.

Search the Internet

1. Tap **Browser**.
2. Enter a search term or URL.
3. Tap the Web site you want to open.



Use Internet Sharing

Use Internet Sharing to allow your computer to use the nüvifone Internet connection. Internet Sharing eliminates the need to have a separate data plan for Internet on your computer.

Your regular Internet and data transfer charges apply.

1. Tap > **Internet Sharing**.
2. Connect your nüvifone to your computer using the USB cable.
3. Use the Internet on your computer.

Read the News

Newstation delivers breaking news and headline news to your device by retrieving the most current news from various Internet news sources.

Your device must be connected to the Internet to use Newstation.

Update News Articles

Automatically Update Articles

1. Tap > **Newstation**.
2. Tap **Menu** > **Settings**.
3. Select an option to set the automatic update parameters.

Manually Update Articles

1. Tap > **Newstation**.
2. Tap a category.
3. Tap **Menu**.
4. Tap **Update** to update the RSS feeds in the selected channel, or tap **Update All** to update the RSS feeds for all channels.

Your news articles are stored as RSS news feeds on your device. You may read the articles without being connected to the Internet.

Read News Articles

1. Tap > **Newstation**.
2. Tap a category and a channel.
3. Tap an article.
4. Tap **Menu** for more options.

Create a New Category

1. Tap > **Newstation**.
2. Tap **Menu** > **New Category**.
3. Enter a category name.

Add a Channel

1. Tap > **Newstation**.
2. Tap a category.
3. Tap **Menu** > **New Channel**.
4. Select an import method:
   - Tap **Input from URL**, enter the URL address, and tap **Next**.
   - Tap **Import from a file** > **Next**. Select a folder and a file. Select a channel, and tap **Next**.
5. Select a category for this new channel.
6. Tap **Finish**.

Edit a Channel

1. Tap > **Newstation**.
2. Tap a category, and tap a channel.
3. Tap **Menu** > **Properties**.
4. Change the information for the channel.
5. To automatically update the selected channel, select the **Auto update this channel** check box.

Export Content

1. Tap > **Newstation**.
2. Select an item to export:
   - To export a category, tap a category, and tap **Menu** > **Export Category**.
   - To export a channel, tap a category and a channel, and tap **Menu** > **Export Channel**.
3. Enter the necessary information.

Play Music

The music player supports the following file types:

- MP3
- WMA
- AAC/AAC+
- WAV

The music library automatically includes all songs you have saved in all of the following locations:

- My Documents\My Music
- My Storage\MUSIC
- MUSIC

For more information on copying files from your computer to your device, see ActiveSync Help on your computer.

Play a Song

1. Tap **Music** > .
2. Tap a category. Drag the bar at the top of the screen to show more categories.
3. Tap a subcategory, if necessary.
4. Tap a song in the list. The music player plays the song and the following songs in the list.
5. Tap the progress bar and drag to jump to a different point in the song.
6. Tap for more options.

Save a Song as a Ring Tone

1. Tap **Music** > .
2. Select a song.
3. Tap > **Save as Ring Tone**.
4. Tap and drag the pointers to select the portion of the song you want to save as a ring tone.
5. Tap **Preview** to play a preview of the selected portion of the song.
6. Tap **Save**.

Play a Playlist

Tap **Music** > > **Playlists**. In addition to the playlists you have imported from your computer, the following default playlists appear:

- **Recently Added**—includes the last 50 songs you have added to your device.
- **Frequently Played**—includes the 20 songs you have played most often.
- **Recently Played**—includes the last 20 songs you have played.

View Pictures and Videos

The Media Gallery supports the following file types:

- JPEG
- PNG
- BMP
- 3GP
- WMV
- MP4

The Media Gallery automatically displays files you have saved in the following locations:

- My Documents\My Pictures
- My Storage\My Pictures

For more information on copying files from your computer to your device, see ActiveSync Help on your computer.

View a Picture

1. Tap **Media Gallery**.
2. Tap a category and a subcategory, if necessary.
3. Drag to view additional pictures, if necessary.
4. Tap a picture.
   - Tap **+** to zoom in. Tap **–** to zoom out. Tap and hold to quickly zoom.
   - Double-tap the picture to zoom in to the maximum level. Double-tap to zoom out.
   - After you zoom in, drag to view different areas of the picture.
   - Tap to delete the picture from the device memory.
5. Tap for more options.

View a Slideshow

1. Tap **Media Gallery**.
2. Tap a picture.
3. Tap the screen to view additional buttons.
4. Tap .
   - Rotate the device to change the orientation of pictures in the slideshow.
   - To move forward or backward through the slides, press the **Navigation** key right or left.
   - Tap the screen to display the Slideshow controls.

Play a Video

1. Tap **Media Gallery**.
2. Tap a category.
3. Tap a video.
4. Tap **Play**.
5. Tap the screen to view the video controls.
6. Drag the progress bar to jump to a different spot in the video.
7. Tap to delete the video from the device memory.
8. Tap for more options.

Play a Video Stream

1. Tap > **Streaming Player**.
2. Tap **Open**.
3. Tap **Connect with tracking history or manual input**, manually enter the stream hyperlink, or select it from the drop-down list in the History link.
4. To select a link from a bookmark, tap **Connect with Bookmark**.
5. Tap **Connect** to start streaming.

Adjust Playback Volume

- Tap **Volume up +** to increase the volume or tap **Volume down -** to decrease the volume of Streaming Player.
- Tap **Mute** to set the player into mute mode, or tap it again to restore volume.

Play a Stream at a Specific Point

1. Play a stream from the network.
2. Tap and drag the slider to where you want to continue playback. (On-demand streaming only)

Manage Bookmarks

1. When the stream is playing, tap **Menu** > **Add to Bookmark**.
2. Tap **Menu** > **Bookmark Manager** to manage the Bookmarks and create new folders.
3. While adding/editing a bookmark entry, confirm or change the name and select a folder to store the bookmark entry.

Use the Camera

Take a Picture

1. Tap **Camera**.
2. Aim the viewfinder.
3. Tap **+** and **–** to zoom in and zoom out.
4. Tap the center of the screen to focus automatically.
5. Press the center **Navigation** key to take a picture.
6. Tap **Camera** to take more pictures, or tap **Menu** for the following options:
   - **Save to Contacts**—select a contact, and save the picture for that contact.
   - **Send via MMS**
   - **Send via e-mail**
   - **Open in Media Gallery**—view the picture.

NOTE: If you are receiving GPS signals, you can set the camera mode to record location information for the pictures you take.

Change the Camera Mode

1. Tap **Camera**.
2. Tap to select a camera mode:
   —take still photographs.
   —record a video.
   —place a frame around the photo.
   —take photos with GPS location information.
   —take a lower-resolution photo for sending using MMS.
   —take a lower-resolution video for sending using MMS.

TIP: To quickly switch modes between the camera mode and video mode, press the left **Navigation** key.

Record a Video

1. Tap **Camera**.
2. Tap .
3. Tap or .
4. Tap **+** and **–** to zoom in and zoom out.
5. Tap the center of the screen to focus automatically.
6. Press the center **Navigation** key to begin recording the video.
7. Press the center **Navigation** key or tap **Stop** to stop recording the video.
8. Tap **Camera** to record more videos.

MPEG-4 EULA

This product is licensed under the MPEG-4 Visual Patent Portfolio License for the personal and non-commercial use of a consumer for (i) encoding video in compliance with the MPEG-4 visual standard ("MPEG-4 Video") and/or (ii) decoding MPEG-4 video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed by MPEG LA to provide MPEG-4 video. No license is granted or shall be implied for any other use. Additional information including that relating to promotional, internal, and commercial uses and licensing may be obtained from MPEG LA, LLC. See www.MPEGLA.com.

AVC EULA

This product is licensed under the AVC Patent Portfolio License for the personal and non-commercial use of a consumer to (i) encode video in compliance with the AVC standard ("AVC Video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, LLC. See www.MPEGLA.com.

Organize Your Life

Synchronize your phone with your computer to keep your task list and calendar up-to-date in both locations.

Use the Calendar

Use the calendar to schedule appointments, including meetings and other events. You can also set the calendar to remind you of your appointments. If you use Microsoft® Office Outlook® on your computer, you can synchronize appointments between your phone and computer.

Open the Calendar

Use one of the following methods to open the calendar:

- From the Home screen, tap **Calendar**.
- Tap > **Calendar**.

Schedule an Appointment

1. From the Home screen, tap **Calendar**.
2. Tap **Menu** > **New Appointment**.
3. Enter information about the appointment.
4. To schedule an all-day event, in **All Day**, tap **Yes**.
5. To make this appointment recurring, tap **Menu** > **Edit** > **Occurs** and select one of the recurrence options.
6. Tap **OK**.

View the Appointments for Today

1. Tap > **Calendar**.
2. Tap **Menu** > **Go to Today**.

To view your agenda for a specific date, tap **Menu** > **Go to Date**. Tap the date to view.

Use Tasks

The task list is your "things to do" list. A task that has been marked as high priority is preceded by an exclamation mark, and a low priority task is marked by a downward-pointing arrow. Overdue tasks are displayed in bold red.

Create a Task

1. Tap > **Tasks** > **Menu** > **New Task**.
2. Enter the task name and details, and tap **OK**.

Mark a Task as Completed

1. Tap > **Tasks**.
2. Select the task to mark complete, and tap **Complete**.

To change the task back to incomplete, tap **Activate**.

Find a Task

1. Tap > **Tasks**.
2. Tap **Menu** > **Sort by** and select a sort option or **Menu** > **Filter** and select a category.

Set the Clock and Alarms

The current date and time appear on the Home screen. By default, the clock is automatically set to your current time zone.

Use one of the following methods to open the Clock and Alarms settings:

- Tap the date and time on the Home screen.
- Tap > **Settings** > **System** > **Clock & Alarms**.

Set the Clock Automatically

1. Tap the date and time on the Home screen.
2. Select the **Set Automatically** check box.
3. Tap **OK** to save your changes. A message box appears asking if you want to update the date and time now.
4. Select an option:
   - Tap **Yes** to turn off the phone and turn it on again automatically.
   - Tap **No** to update the date and time the next time you turn off the phone and turn it on again.

When the phone updates the date and time settings, a prompt appears. Tap **Home** or **Visiting**, and then tap **Save** to update the settings. Tap **Cancel** to exit without updating the settings.

Set the Clock Manually

1. Tap the date and time on the Home screen.
2. Clear the **Set Automatically** check box.
3. Tap **Home** to set the clock for your home location, or **Visiting** to set the clock for a location you are visiting.
4. Tap the time zone, and select a time zone.
5. Tap the hours or minutes, and then tap the arrows, or press the **Navigation** key to set the time.
6. Tap **AM** or **PM**, and then tap the arrows or press the **Navigation** key to change the value.
7. Tap the month, and then tap the arrow to select the date from the calendar.
8. Tap **OK** to save your changes.

Set an Alarm

1. Tap the date and time on the Home screen.
2. Tap the **Alarms** tab.
3. Tap **New**.
4. Tap the hours or minutes, and then tap the arrows or press the **Navigation** key to set the time.
5. Select an alarm type.
6. Tap **Snooze**, and then select a snooze time.
7. Tap **Sound**, and then select an alarm sound. Tap **Others** to select a sound file (.mp3, .wav, or .mid) you have saved on your phone. Tap **Play** to preview the selected sound. Use the slider to adjust the volume of the sound.
8. Tap **OK** to save.

Edit or Delete an Alarm

1. Tap the date and time on the Home screen.
2. Tap the **Alarms** tab.
3. Tap an alarm, and then tap **Edit** or **Delete**.

Display the Clock in the Status Bar

1. Tap the date and time on the Home screen.
2. Tap the **More** tab.
3. Select the **Display the clock on the title bar in all programs** check box.

Convert Currency

A data connection is required for this feature.

1. Tap > **Tools** > **Currency Converter**.
2. Tap a currency button to change the currency, and tap a currency.
3. Repeat to select the second currency.
4. Tap the rectangle below the currency you want to convert.
5. Enter the number, and tap **Done**.

Update Conversion Rates

1. Tap > **Tools** > **Currency Converter**.
2. Tap **Update**.

The nüvifone accesses Connected Services to update the conversion rates.

Microsoft® Office Mobile

Your device comes with pre-installed Microsoft Office Mobile applications. Use these applications like you would normally use the Office applications on your computer.

To access these applications, tap > **Office Mobile**. Select the appropriate application to use.

Microsoft® Office Excel® Mobile

Create, view, and edit spreadsheets on your device using Excel® Mobile. Any editing or formatting you have done to an Excel Mobile file is kept intact when you open the file on your computer.

Excel Mobile is compatible with Microsoft® Office Excel 2007.

Microsoft® Office OneNote® Mobile

Take notes with OneNote Mobile. You can also insert audio recording and pictures to your notes.

Microsoft® Office Word Mobile

View and edit Word documents on your device with Word Mobile. Any editing or formatting you have done to a Word Mobile file is kept intact when you open the file on your computer.

Word Mobile is compatible with Microsoft Office Word 2007.

Microsoft® Office PowerPoint® Mobile

View presentations using PowerPoint Mobile. It is compatible with Microsoft Office PowerPoint 2007.

Synchronize Your nüvifone

You can synchronize contents and transfer data between your device and your computer using Microsoft® ActiveSync on Windows® XP operating systems.

During synchronization, ActiveSync compares the data in your device with the data in your computer or Exchange Server, and updates all data with recent changes.

For detailed information about ActiveSync, see the Active Sync Help file.

To synchronize on Windows Vista™ operating systems, use Microsoft® Windows Mobile Device Center. Go to www.microsoft.com/windowsmobile/devicecenter.mspx.

Install and Configure ActiveSync on Your Computer

1. Insert the Getting Started CD-ROM in your computer's CD-ROM drive.
2. Follow the on-screen instructions.
3. Connect your device to the computer using the mini-USB cable or Bluetooth technology. See page 73.
4. Follow screen instructions to complete the wizard.
5. Disconnect the device after the synchronization is complete.

Each time you connect your nüvifone to your computer, your nüvifone is automatically synchronized with your computer.

Synchronize Using the USB Cable

1. Install ActiveSync on your computer.
2. Connect the mini-USB plug to the mini-USB connector on the bottom of the device.
3. Connect the other end of the USB cable to your computer.
4. If the USB Connection Mode page appears, tap **ActiveSync** > **OK**. ActiveSync synchronizes your device.

NOTE: You can only synchronize media files, such as music and video files, using a USB cable.

Enable the USB Connection Mode Page

The USB Connection Mode page allows you to select a USB connection mode when you connect your device to your computer. This page only appears when you connect your device to your computer using a USB cable.

1. Tap > **Settings** > **Connections** > **USB Setting**.
2. Select the **Ask When I Connect Device** check box.
3. Connect the mini-USB plug to the mini-USB connector on the bottom of the device.
4. Connect the other end of the USB cable to your computer. The USB Connection Mode page appears.
5. Select an option.
6. Tap **OK**.

Mass Storage Mode

Applications cannot access data stored in My Storage while in Mass Storage mode. You can use Mass Storage mode when the computer does not have ActiveSync installed.

Synchronize with an Exchange Server

ActiveSync can also synchronize over a wireless or mobile network with Microsoft Exchange Server, which allows you to sync your e-mail messages. Your mobile phone service or company must be running Microsoft Exchange Server with Exchange ActiveSync.

For detailed information about ActiveSync, see the Active Sync Help file.

Synchronize Using Bluetooth® Technology

Your computer must have a Bluetooth component to synchronize using Bluetooth technology.

NOTE: You can only synchronize media files, such as music and video files, using a USB cable.

1. Enable Bluetooth on your computer.
2. Connect your nüvifone with your computer using Bluetooth. See page 73.
3. From your device, tap > **ActiveSync** > **Menu** > **Connect via Bluetooth**.
4. When connected, tap **Sync** to synchronize data.

Backup and Restore Files

IMPORTANT: Some system functions may be suspended or terminated during the backup process or the restore process. When finished, reset your device to revive suspended functions.

Backup

NOTE: If you enter a password when you create the backup file, you will need the password to restore the backup file.

1. Tap > **Backup**.
2. Tap **Backup**.
3. Select the items you want to back up, and tap **Next**.
4. Follow the on-screen instructions to create the backup file.

Restore

1. Tap > **Backup**.
2. Tap **Restore**.
3. Select the backup file you want to restore, and tap **Next**.
4. Follow the on-screen instructions to restore the backup file.

Search for Files

Search for files and other items stored in your device. You can search by file name or by words located in various applications.

1. Tap > **Search Phone**.
2. Enter the file name or word.
3. Select the data type.
4. Tap **Search**.

Get Connected

Manage Wireless Connections

1. Tap > **Wireless Manager** or tap > **Settings** > **Wireless Manager**. Wireless Manager shows the connection status of your device.
2. Tap an option to enable or disable it. The icon is yellow when enabled, and white when disabled.

Change Connection Settings

1. Tap > **Settings** > **Wireless Manager** > **Settings**.
2. Select an option to adjust those settings.
3. Tap **Auto Switch Settings** to set up the times to turn on and off features of the device.

Turn Off the Phone

1. Tap > **Settings** > **Wireless Manager**.
2. Tap **Phone**.

Turn on Flight Mode

1. Tap > **Settings** > **Wireless Manager**.
2. Tap **Flight Mode** to turn on Flight Mode.

When Flight Mode is on, the telephone, the network, Bluetooth, and GPS features are deactivated. You cannot send or receive new e-mail or SMS/MMS messages.

Set Up a Wi-Fi Connection

1. Tap > **Settings** > **Wireless Manager**.
2. Tap **Wi-Fi** to turn on Wi-Fi.

Enable Wi-Fi Sharing

With Wi-Fi Sharing on, you can share your network connection with others, making your device a Wi-Fi router. When Wi-Fi Sharing is on, you cannot use the Internet on your device.

1. Tap > **Settings** > **Wireless Manager**.
2. Tap **Wi-Fi Sharing**.
3. Tap **OK** > **Connect**.
4. Use one of the following methods to end Wi-Fi Sharing:
   - From the Wi-Fi Sharing page, tap **Menu** > **Exit**.
   - Tap > **Settings** > **Wireless Manager** > **Wi-Fi Sharing**.

About Bluetooth

Bluetooth wireless technology establishes a wireless connection between devices, such as a computer with Bluetooth technology and the nüvifone. To pair and connect, both devices must be turned on and be within 10 meters of each other.

With Bluetooth enabled in your device, you can synchronize, transfer files, and share services.

For more information about Bluetooth technology, see tap > **Help**.

Turn On Bluetooth Technology

1. Tap > **Settings** > **Wireless Manager**.
2. Tap **Bluetooth**.

TIP: When not in use, turn off Bluetooth to conserve battery power.

Make a Device Visible

Other devices with Bluetooth capabilities can detect your device and attempt to beam information to it, establish a partnership, or use a Bluetooth service.

1. Tap > **Settings** > **Connections**.
2. Tap **Bluetooth** > **Mode** tab.
3. Select the **Turn on Bluetooth** check box, select the **Make this device visible to other devices** check box, and then tap **OK**.

If you do not want your nüvifone to be visible to other devices, remove the check mark from the **Make this device visible to other devices** check box.

Add a Bluetooth Device

The first time you use two devices together, you must "pair" them by establishing a relationship using a PIN/passkey.

1. Enable the Bluetooth component and Find Me/Discoverable/Visible mode on the device to which you are connecting. These settings might be in a Bluetooth, a Connections, or a Hands-free menu.
2. On the nüvifone, tap > **Settings** > **Connections**.
3. Tap **Bluetooth** > **Devices** tab > **Add new device**.
4. Select the device you want to connect to, and tap **Next**.
5. Enter the alphanumeric passkey of the device you want to connect to, and tap **Next**. You can find the passkey in the documentation that came with the target device.
6. Enter the display name for this connection.

NOTE: The Bluetooth passkey for the nüvifone is **1234**.

After the initial pairing, the two devices can connect automatically

each time you turn them on.

Send Files

You can send files to another device using Bluetooth wireless technology.

1. Pair and connect the nüvifone with the device you want to exchange files with.
2. Tap > **File Explorer**.
3. Select the file, and tap **Menu** > **Beam File**. A list of Bluetooth devices appears.
4. Select a the device in the list. The file is sent.

Exchange Files Using FTP

You can exchange files between two Bluetooth devices by enabling the file transfer server and/or client.

Configure the File Transfer Services

1. Tap > **Settings** > **Wireless Manager** > **Settings** > **Bluetooth Settings** > **FTP** tab.
2. Change the root directory, if necessary. The remote client is not able to view files outside of this directory.
3. Select the **Use server authorization** check box, if necessary.
4. Tap **OK**.

Customize Your nüvifone

Adjust the Backlight

Adjust the Brightness

1. Tap > **Settings** > **System** > **Brightness**.
2. Adjust the brightness.

Adjust the Backlight Timeout

1. Tap > **Settings** > **System** > **Backlight**.
2. Adjust the how the backlight operates when the device is running on battery power and on external power.

Keep the Backlight on When Navigating

1. Tap > **Settings** > **Navigation** > **Backlight Override**.
2. Tap **On When Navigating** > **OK**.

Align the Screen

Align the screen to ensure that the item you tap on the screen is selected.

1. Tap > **Settings** > **System** > **Screen**.
2. On the **Alignment** tab, tap **Align Screen**, and follow the on-screen instructions.

Orient the Screen

1. Tap > **Settings** > **System** > **Screen Orientation**.
2. Select a portrait or landscape screen orientation.

Change the Lock Settings

1. Tap > **Settings** > **Personal** > **Lock**.
2. Select an option:
   - **Simple PIN**—enter a 4-character PIN to unlock the screen.
   - **Strong Alphanumeric**—enter a 7-character password to unlock the screen.
3. Tap **OK** to save the changes.

Set Up Auto Cleaner

Use Auto Cleaner to close the running applications you are not using.

1. Tap > **Settings** > **System** > **Auto Cleaner**.
2. Select how to close and exit programs.

Change the Appearance

Edit the Home Screen Shortcuts

You can include up to 30 shortcuts on the Home screen.

1. Tap and hold any shortcut in the middle section of the Home screen for two seconds.
2. Drag an icon to a new location or to the trash can.
3. To add an icon, tap . Select an application, and tap **Add**.
4. Tap to save your changes.

To restore the Home screen to the original layout, tap .

Change the Home Screen Theme

1. Tap > **Settings** > **Appearance** > **Theme**.
2. Select a theme for the Home screen.

Change the Wallpaper

1. Tap > **Settings** > **Appearance** > **Idle Screen Image**.
2. Tap **Picture**.
3. Select a picture to use for the Home screen wallpaper.

Customize the Today Screen

1. Tap > **Settings** > **Personal** > **Today** > **Items** tab.
2. Select items to appear in the Today screen.

Customize the Call Settings

Change the Profile

1. Tap > **Settings** > **Sound** > **Profile**.
2. Tap a profile to use.

Set the Ring Tone

1. Tap > **Settings** > **Sound** > **Ring Tone**.
2. Select a ring tone.
3. Tap **Play** to play the selected ring tone.

Set the Ring Type

1. Tap > **Settings** > **Sound** > **Ring Type**.
2. Tap a ring type, such as **Vibrate**.

Change the Advanced Sound Settings

1. Tap > **Settings** > **Sound** > **Advanced**.
2. Select the items you want to hear a sound for.

Automatically Answer Phone Calls

1. Tap > **Settings** > **Personal** > **Phone** > **Auto Answer** tab.
2. Select the check box to enable the auto answer function.
3. Select how long the device will wait before answering the call.

Activate Connection Alert

1. Tap > **Settings** > **Personal** > **Phone** > **Call Setting** tab.
2. Select an alert indication when the call is answered.

Configure Your Phone Network Profile

If the network settings for your phone service provider are not detected when you install the SIM card, you can select the network.

GPRS, WAP, and MMS settings are also configured by the Network Setting.

Automatic Configuration

1. Tap > **Settings** > **Connections** > **Network Setting**.
2. Tap **Auto Detect** to detect the mobile phone service provider (operator) according to your SIM card.
3. Tap **Done**.

Manual Configuration

1. Tap > **Settings** > **Connections** > **Network Setting**.
2. Select your country.
3. Select your mobile phone service provider (operator).
4. Tap **Done**.

Switch Between GSM and 3G Networks

Choose the right network type for your SIM card.

1. Tap > **Settings** > **Connections** > **GSM/3G Networks**.
2. From the **Network** box, tap a network or tap **Automatic**. 3G network has priority over GSM network when **Automatic** is selected.
3. Tap **OK**.

Use SMS Cell Broadcast

If SMS Cell Broadcast is supported by your service provider and region, you can receive text messages broadcast to multiple subscribers in the area.

1. Tap > **Settings** > **Personal** > **Phone** > **Channels** tab.
2. Select the **Enable SMS Cell Broadcast** check box.
3. Tap **Set Languages**, select one or more languages, and tap **OK**.
4. Tap **Set Channels**, select one or more channels, and tap **OK**.

Add a New Channel

1. Tap > **Settings** > **Personal** > **Phone** > **Channels** tab > **Set Channels** > **New**.
2. Enter the channel name and number, and tap **OK**.

Adjust the Navigation Settings

Adjust the Map Settings

1. Tap > **Settings** > **Navigation** > **Map**.
2. Tap a setting to adjust it.
   - **Map Detail**—adjust the amount of detail shown on the map. Showing more detail may cause the map to redraw slower.
   - **Orientation**—select **3 Dimensional** to display the map in 3 dimensions (3D) with your direction of travel at the top; **Track Up** to display the map in two dimensions (2D) with your direction of travel at the top; or **North Up** to display the map in 2D with North at the top.
   - **Show Location**—show your location on the nearest road or at your GPS location.

- **Auto Zoom**—select **Enabled** to have the map automatically zoom to show the next turn on the map.
- **Show Speed Limit—**select **Yes** to display the speed limit as you travel on major roadways.
- **Metro Areas**—select **Enabled** to shade metropolitan areas of the map.
- **Vehicle**—select an icon used to display your position on the map.
- **Outline Detailed Maps**—select **Yes** to display lines around the built-in detailed maps.
- **Lat/Lon Grid**—select **Enabled** to display the latitude/longitude grid.
- **Favorites**—select the text size for locations that appear on the map or turn off text labels.
- **POI**—select the text size for POIs on the map or turn off text labels.

Change the Routing Settings

1. Tap > **Settings** > **Navigation** > **Routing**.
2. Tap a setting to adjust it.
   - **Calculate Routes for**—select your vehicle type to optimize routes.
   - **Off–Route Recalculation**—select how the nüvifone notifies you when you are off your route.
   - **Route Preference**—select a preference for calculating your route.
   - **Turn Preview**—select **Enabled** to show a brief preview of upcoming turns.

- **Avoidance Setup**—select the types of roads or areas you want to avoid in routes. the nüvifone avoids using these items in a route unless there is no alternative. See page 35.

Change the Audio Settings

1. Tap > **Settings** > **Navigation** > **Audio**.
2. Tap a setting to adjust it.
   - **Voice Prompt**—turn on and off the vocal navigation prompts.
   - **Attention Tone**—turn on and off the tone that is sounded before a navigation prompt.

Adjust the Proximity Points Settings

1. Tap > **Settings** > **Navigation** > **Proximity Points**.
2. Tap a setting to adjust it.
   - **Custom POI Sets**—turn on and off the custom POI (points of interest) sets you have loaded in the nüvifone.
   - **Safety Cameras**—turn on and off the Safety Camera databases you have loaded in the nüvifone.
   - **Audio Notification**—select how you want to be audibly notified when you approach a custom POI or a safety camera location.

Change the Units of Measure

1. Tap > **Settings** > **Navigation** > **General**.
2. Select units of measure for distance and speed, direction, elevation, and temperature.

Turn On and Off Safe Mode

1. Tap > **Settings** > **Navigation** > **General** > **Safe Mode**.
2. Tap **Enabled** to turn on safe mode.

When your vehicle is moving, safe mode disables all functions that require significant operator attention and could become a distraction while driving.

Change the Location Format and Map Datum

1. Tap > **Settings** > **Navigation** > **General**.
2. Tap a setting to adjust it.
   - **Location Format**—select a format for the latitude and longitude coordinates that matches the paper map you are using. If you select **User UTM Grid**, enter the appropriate coordinate information.
   - **Datum**—select a map datum that matches the paper map you are using. The datum is generally listed in the map's legend.

Change Connected Services Settings

1. Tap > **Settings** > **Navigation** > **Connected Services**.
2. Tap a setting to adjust it.
   - **Connected Services Access**—select how to connect to access Connected Services.
   - **Location Updates**—select to send location updates manually or automatically.
   - **Connected Services Feedback**—enable to periodically send anonymous location information from your phone. Your regular data transfer charges apply.

Change the GPS Settings

1. Tap > **Settings** > **Navigation** > **GPS**.
2. Tap a setting to adjust it.

- **Auto Update**—select how the nüvifone automatically updates the GPS information.
- **Update When Sync**—select whether the nüvifone automatically updates the GPS information when you sync the nüvifone to your computer.
- **GPS Data Update**—view the information for the last time the GPS data was updated. Tap **Update** to update the GPS data now.
- **GPS Status**—view information about the GPS satellites your device is receiving and their signal strength.

Set Your Location

When you activate the GPS for the first time, or if you have traveled more than 600 miles with the GPS receiver turned off, the GPS must initialize. To shorten the time it takes to acquire satellites, set your location on the map.

1. Tap > **Settings** > **Navigation** > **GPS**.
2. Tap **GPS Status**.
3. Tap > **New Location**.
4. Tap a point on the map near your current location, and tap **OK**.

Turn Off GPS

1. Tap > **Settings** > **Navigation** > **GPS**.
2. Tap **GPS Status**.
3. Tap > **Disable GPS**.

Change the Camera and Video Settings

Change the Basic Camera Settings

1. Tap **Camera**.
2. Tap **Menu** to adjust the following settings:

   —select a size for the photos.

—turn on when taking close up photos.

—select a count-down time for taking self-portraits.

—open the advanced Camera settings page.

TIP: To quickly adjust these settings, tap the corresponding icon along the top of the screen.

Change the Advanced Camera Settings

1. Tap **Camera** > **Menu** > .
2. Tap the **Camera** tab.
3. Adjust the following settings:
   - **Picture Quality**—select a quality. The finer the quality, the larger the file size.
   - **File Number**—tap **Reset #** to reset the auto-numbering for the photos.
   - **Date and Time Stamp**—add a date and time stamp to the photos.
   - **Shutter Sound**—play a sound when you take a photo.

Change the Camera Color Settings

1. Tap **Camera** > **Menu** > .
2. Tap the **Color Adjustment** tab.
3. Adjust the following settings:
   - **White Balance**—select the setting, such as **Sunny** or **Cloudy**, to achieve the color that you want in your photos.

- **Effect**—select an effect: **Normal**, **Black-and-White**, **Negative**, or **Sepia**.
- **Brightness**, **Sharpness**, and **Saturation**—adjust the settings as needed.
- **Default**—restore the original settings.

Change the General Camera Settings

1. Tap **Camera** > **Menu** > .
2. Tap the **General** tab.
3. Adjust the settings:
   - **Save To**—select the location to which you want to save the pictures you take.
   - **AC Frequency**—select a frequency.
   - **Metering Mode**—select a metering mode.
   - **Camera Power Saving Mode**—place a check mark in the box and enter a length of time.
   - **Use Preview Mode**—place a check mark in the box to preview the pictures you take prior to saving them.
   - **Restore Default Value**—restore the default settings.

Change the Video Settings

1. Tap **Camera** > **Menu** > .
2. Tap the **Video** tab.
3. Adjust the settings:
   - **File ext**—select the file type: MP4 or 3GP.
   - **File Number**—tap **Reset #** to reset the auto-numbering for the videos.

- **Include Audio when recording Video**—select the box to include audio, or clear the check box to record video without audio.

View Device Information

The About page contains information about the nüvifone, including software version, unit ID, and copyright information.

1. Tap > **Settings** > **About**.
2. Select an option.

View System Information

1. Tap > **Settings** > **System** > **System Information**.
2. Tap the **Device Info** tab and the **Version** tab.

Restore the Default Settings

This process restores all settings to factory defaults and deletes all user-entered information.

CAUTION: Items that you have saved on your device (such as Favorites) are erased. Files saved in My Storage and map data are not erased. Deleted information cannot be recovered.

1. Tap > **Settings** > **System** > **Default Settings**.
2. Enter **1234**, and then tap **OK**.

All original settings are restored. Any items that you have saved are erased.

Appendix

nüMaps Guarantee™

To receive one free map update (if available), register your nüvifone at www.garminasus.com within 60 days of acquiring satellites and driving with your nüvifone. You are not eligible for the free map update if you register by phone or wait longer than 60 days after the first time you drive with your nüvifone.

Additional Maps

You can purchase additional maps for your nüvifone. To see a list of maps that are compatible with your nüvifone, go to (www.garminasus.com/nuvifoneM20).

Update the Software

Go to www.garminasus.com/nuvifoneM20 to download the latest software update.

Reset the nüvifone

If the nüvifone stops functioning, turn off the nüvifone, and then turn on the nüvifone.

If this does not help, remove the battery cover. Using the stylus, press the red Reset button. The nüvifone should restart and operate normally.

Battery Information

The battery icon in the status bar indicates the status of the internal battery. To increase the accuracy of the battery gauge, fully discharge the battery and then fully charge it; do not unplug the nüvifone until it is totally charged.

Maximize the Battery Life

- Turn down the backlight at > **Settings** > **System**.
- Do not leave your nüvifone in direct sunlight. Avoid prolonged exposure to excessive heat.

Replace the Battery

If you need to replace the battery in the nüvifone, use an SBP-20 lithium-ion battery. For more information on purchasing a replacement battery, go to www.garminasus.com.

CAUTION: Only use the correct battery type. Using an incorrect battery may present a risk of explosion.

CAUTION: Do not use a sharp object to remove the battery. A sharp object may puncture the battery which may present a risk of fire, chemical burn, electrolyte leak, and/or injury.

To avoid losing your customized settings, replace the battery within five minutes of removing it from your device.

Contact your local waste disposal department for information on properly disposing of the battery and device.

Acquire GPS Satellite Signals

Your nüvifone must acquire GPS (Global Positioning System) satellite signals to navigate. The nüvifone automatically attempts to acquire satellite signals.

If you are indoors, near tall buildings or trees, or in a parking garage, your nüvifone might not acquire satellites. To acquire satellite signals more quickly, take your nüvifone outside, to an area free from tall obstructions.

Change the Fuse in the Vehicle Power Cable

CAUTION: When replacing the fuse, do not lose any of the small pieces and make sure they are put back in the proper position.

If your device does not charge in your vehicle, you may need to replace the fuse located at the tip of the vehicle adapter.

1. Unscrew the end piece, and remove it.
2. Remove the fuse (glass and silver cylinder), and replace with a 1A fast blow fuse of the same size.
3. Ensure that the silver tip is located in the end piece. Screw on the end piece.



Mount on Your Dashboard

A mounting disk is included in some nüvifone packages. Use the mounting disk to mount your device to the dashboard and comply with certain state and local regulations.

CAUTION: The **permanent** mounting adhesive is extremely difficult to remove after it is installed.

1. Clean and dry the dashboard where you are placing the disk.
2. Remove the backing from the adhesive on the bottom of the disk.
3. Place the disk on the dashboard.
4. Remove the clear plastic cover from the top of the disk.
5. Place the suction cup mount on top of the disk. Flip the lever down (toward the disk).

Specifications

Physical size (W × H × D):
52.57 × 95.3 × 12.8 mm
(2.31 × 3.75 × 0.504 in.)

Weight: 99 g (3.49 oz.)

Display: 2.8 in. diagonal, 640 × 480 pixels; VGA display with white backlight and touchscreen

Case: Not waterproof (IP51)

Operating Temperature Range: from 5°F to 113°F (from -15°C to 45°C)

Storing Temperature Range: from 5°F to 140°F (from -15°C to 60°C)

AC Charger Operating Temperature Range: from 32°F to 122°F (from 0°C to 50°C)

Connector: mini-USB for power, computer, or headphones

Battery type: User-replaceable 920 mA lithium-ion battery

Standby Time for 2G: up to 260 hours

Standby Time for 3G: up to 250 hours

Talk Time for 2G: up to 2.8 hours*

Talk Time for 3G: up to 3.5 hours*

* Depending on network environment and phone usage.

Charge time: Approximately 4 hours

Power input: DC vehicle power using vehicle power cable, or AC power using USB cable or AC charger

GPS receiver: High-sensitivity

Acquisition times*:
Warm: <1 sec.
Cold: <38 sec.
Factory Reset: <45 sec.
*Average acquisition times for a stationary receiver with a clear view of the sky.

Frequency Band: 3G 900/2100; 2G 900/1800/1900

Frequency Band for NA: 3G 850/1900; 2G 850/1800/1900

Other connectivity: Bluetooth 2.0+EDR; 802.11 b/g WLAN; mini USB 2.0

OS: Microsoft Windows® Mobile 6.5 Professional

Camera/Photos: 3.0 MP camera

Data storage: 4 GB Internal memory; Data stored indefinitely

Computer interface: plug-and-play USB mass storage, ActiveSync

Important Safety and Product Information

For updates to the safety and product information, see the most recent owner's manual at www.garminasus.com/nuvifoneM20.

Warnings

CE 0700 ⓘ

Failure to avoid the following potentially hazardous situations could result in an accident or collision resulting in death or serious injury.

General Device Warnings:

- When installing the device in a vehicle, place the device securely so it does not obstruct the driver's view of the road or interfere with vehicle operating controls, such as the steering wheel, foot pedals, or transmission levers. Do not place in front of or above any airbag.
- **Do not become distracted by the device while driving, and always be fully aware of all driving conditions.**
- Always operate the vehicle in a safe manner.
- Minimize the amount of time spent viewing the device's screen while driving and use voice prompts when possible.
- Do not send text messages, place or receive phone calls, input destinations, change settings, or access any functions requiring prolonged use of the device's controls while driving. Pull over in a safe and legal manner before attempting such operations.
- Check and follow local laws regarding device usage.

Navigation Warnings:

- When navigating, carefully compare information displayed on the device to all available navigation sources, including information from street signs, visual sightings, and maps. For safety, always resolve any discrepancies or questions before continuing navigation and defer to posted road signs.
- The device is designed to provide route suggestions. It is not designed to replace the need for driver attentiveness regarding road closures or road conditions, traffic congestion, weather conditions, or other factors that may affect safety while driving.

Battery Warnings

If these guidelines are not followed, the internal lithium-ion battery may experience a shortened life span or may present a risk of damage to the GPS device, fire, chemical burn, electrolyte leak, and/or injury.

- Do not leave the device exposed to a heat source or in a high temperature location, such as in the sun in an unattended vehicle. To prevent damage, remove the device from the vehicle or store it out of direct sunlight, such as in the glove box.
- Do not puncture or incinerate.
- When storing the device for an extended time, store within the following temperature range: 5°F to 140°F (from -15°C to 60°C).
- Do not operate the device outside of the following temperature range: 5°F to 113°F (from -15°C to 45°C).
- Contact your local waste disposal department to properly recycle/dispose of the device/battery.

Additional User-replaceable Battery Warnings:

- Do not use a sharp object to remove the battery.
- Keep the battery away from children.
- Do not disassemble, puncture, or

damage the battery.

- If using an AC charger or external battery charger, only use the accessory approved for your product.
- Only replace the battery with the correct replacement battery. Using another battery presents a risk of fire or explosion. To purchase a replacement battery, see your Garmin or ASUS dealer or the Garmin-Asus Web site.

Additional Non-user-replaceable Battery Warnings:

- Do not remove or attempt to remove the non-user-replaceable battery.
- When disposing of the device, take it to a professional service, such as a waste electronics treatment facility, to have the battery removed and recycled.

Pacemakers and Other Medical Devices

Studies have shown that there may be a potential interaction between mobile phones and normal pacemaker operation. The pacemaker industry recommends that people with pacemakers follow these guidelines to minimize any risk of interference with pacemaker operation:

- Always maintain a distance of 15 cm (6 inches) between the pacemaker and any mobile phone that is turned on.
- Store the phone on the opposite side of the pacemaker. Do not carry the phone in a breast pocket.
- Use the ear furthest from the pacemaker in order to minimize any potential for interference.
- If you think that interference may be occurring, turn off the phone immediately.

For other medical devices, consult with your physician or the manufacturer to determine if your mobile phone may interfere with the device, and to determine any precautions that you can take to avoid interference.

Avoid Hearing Damage

You can permanently damage your ears and lose hearing if you listen to the receiver, earbuds, headphones, or headsets at high volume.

Turn the volume down. The volume is typically too loud if you cannot hear people speaking around you. Limit the amount of time you listen at high volume.

If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked.

Avoid Repetitive Motion

You may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body if you perform repetitive activities, such as typing or playing games, on the device.

Take frequent breaks. If you have discomfort while or after using the device, stop using and see a physician.

Avoid Seizures, Blackouts, and Eyestrain

A very small percentage of people can experience seizures or blackouts caused by light flashes or patterns, such as while watching videos or playing games.

If you have experienced, or have a family history of, seizures or blackouts, consult a physician before playing games or watching videos on your device.

Follow these guidelines to reduce the risk of blackouts, seizures, and eyestrain:

- Avoid prolonged use of and take frequent breaks from using the device.
- Hold the device away from your eyes.
- Use the device in a well-lit room.

If you experience convulsions, eye or muscle twitching, loss of awareness, involuntary movement, or disorientation, stop using the device use and consult a physician.

Radio Frequency Exposure / Specific Absorption Rate

This device is a transmitter and receiver that uses its antenna to send and receive low levels of radio frequency (RF) energy for voice and data communications. The cellular antenna is located above the camera lens, along the top edge of the back of the device. The Wi-Fi and Bluetooth® antenna is located

to the right of the camera lens on the back of the device.

Regular review of scientific research and studies has led to the formation of international safety guidelines and regulations regarding limiting exposure to this RF energy. This product emits RF energy below the published limits when operating in its maximum output power mode and when used with Garmin-Asus authorized accessories. In normal operation, the device will operate at even lower output power modes, depending on many factors including proximity to network cellular towers and the absence of external interference.

The RF exposure guidelines use a unit of measurement known as the specific absorption rate, SAR. The SAR limit applicable to this device set by the Council of the European Union is 2.0 W/kg. The SAR value for this device for held to head configurations was 0.696 W/Kg.

This device has been tested and is compliant with the European Union RF exposure guidelines for cellular, Wi-Fi, and Bluetooth operation. For countries where this product is sold outside of the United States, Canada, and the European R&TTE member countries, this product has been tested and is compliant to the applicable RF exposure requirements of the local regulatory authority.

To be sure that your exposure to RF energy does not exceed the European Union guidelines, follow these precautions:

- Position the device antenna at least 15 mm (5/8 inch) from your body.
- Only use the device with Garmin-Asus approved accessories. Only use accessories that do not have metal parts and that maintain at least 15 mm (5/8 inch) separation between the device and your body.

Care for Your Device

- Avoid dropping your device and operating it in high-shock and high-vibration environments.
- Do not expose the device to water.

Contact with water can cause this device to malfunction.

- Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.
- Never use a hard or sharp object to operate the touchscreen, or damage may result. Though a stylus can be used to operate the touchscreen, never attempt this while operating a vehicle.
- To help avoid theft, remove the device and mount from sight when not in use. Remove the residue on the windshield left by the suction cup.

Important Information

MAP DATA INFORMATION: One of the goals of Garmin and ASUS is to provide customers with the most complete and accurate cartography that is available to us at a reasonable cost. We use a combination of governmental and private data sources, which we identify in product literature and copyright messages displayed to the consumer. Virtually all data sources contain some inaccurate or incomplete data. In some countries, complete and accurate map information is either not available or is prohibitively expensive.

NOTICE REGARDING WINDSHIELD MOUNTING LEGAL RESTRICTIONS: Before using the suction cup mount on your windshield, check the state and local laws and ordinances where you drive. Some state laws prohibit drivers from using suction mounts on their windshields while operating motor vehicles. Other state laws allow the suction mount to be located only in specific locations on the windshield. Many other states have enacted restrictions against placing “non-transparent material” on the windshield or placing objects on the windshield in locations that obstruct the driver’s vision. **IT IS THE USER’S RESPONSIBILITY TO USE THE GARMIN-ASUS DEVICE AND MOUNTING OPTIONS IN SUCH A MANNER THAT THE USER IS IN COMPLIANCE WITH ALL APPLICABLE LAWS AND**

ORDINANCES. Where required, other Garmin-Asus dashboard or friction mount options should be used to comply with state and local laws and ordinances. Always mount your Garmin-Asus device in a location that does not obstruct the driver's view of the road. Garmin and ASUS do not assume any responsibility for any fines, penalties, or damages that may be incurred as a result of disregarding this notice or as a result of any state or local law or ordinance relating to the use of your Garmin-Asus device.

Declaration of Conformity

Hereby, Garmin and ASUS declare that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. To view the full Declaration of Conformity, see www.garminasus.com/declaration-of-conformity.

Equipment Use

This nüvifone is for use worldwide, including the following countries:

AT	EE	IS	NO
BE	ES	IT	PL
BG	FI	LI	PT
CH	FR	LT	RO
CY	GB	LU	SE
CZ	GR	LV	SI
DE	HU	MT	SK
DK	IE	NL	TR

Troubleshooting Issues

If your device does not acquire satellites, try one or more of the following:

- Make sure the GPS is turned on. Tap > **Settings** > **Navigation** > **GPS** > **GPS Status**, and then verify that you are receiving satellite signals.
- Verify that the GPS antenna is unobstructed. You must be outdoors or in a vehicle and have a clear view of the sky. Solid materials (except untinted glass), buildings, and dense trees can block satellite signals.
- Make sure the GPS has enough time to initialize. When the GPS is turned on for the first time, it may take a few minutes to initialize.
- If you have traveled more than 600 miles with the GPS receiver turned off, set your location on the map.

If your device will not turn on, try one or more of the following:

- Charge the battery.
- Make sure the **Hold** key on the right side of the unit is up. If the red dot near the **Hold** key is visible, the unit is locked.

If you need to turn off the wireless features of your phone, for example for an airplane flight, tap > **Settings** > **Wireless Manager** > **Flight Mode**.

Index

Symbols

2D map view 80

A

ActiveSync
  Bluetooth
    technology 69
  install 67
  USB 68
additional maps 88
address 19
alarm
  delete 65
  edit 65
  set 64
align the screen 75
appointment
  make 61
  navigate to 29
  save local event as 23
  save movie time as 24
  view 62
attention tone 82
audio settings 82
auto complete 11
auto zoom map 81
avoid
  edit custom
    avoidances 35
  road types 82
  specific areas 35
  specific roads 35

B

backlight
  adjust 75
  brightness 75
  keep on when
    navigating 75
  timeout 75
backup files 70
battery
  charge 3
  information 88
  install 2
  remove 89
  warnings 93–94
block recognizer 11
Bluetooth 72
Bluetooth technology 69, 72, 73–74
  add a device 73
  make visible 73
  send and receive
    files 74
  turn on 72
browse the map 36

C

calendar 61
calibrate the screen 75
call 13
  end 13
call history 17
call options 14
camera 59
  color 85
  mode 59
  settings 84, 86
care information 96
cell broadcast 80
Ciao! 39–42
  accept invite 40
  hide location 42
  invite 40
  join 39
  location updates 83
  register 39
  remove a friend 42

status 40, 41
view friends 41–42
cities, find 26
clock
in status bar 65
set 63
set automatically 63
set manually 64
computer connection 68
conference call 15, 16
connected services 43–46
connection 83
settings 83
connections 71
contacts
add 17
favorites 18
navigate to 29
convert currency 65
coordinates 27
cradle 3
currency, convert 65
custom POIs 28
settings 82

D

Declaration of Conformity 98
default
camera 86
input mode 12
restore all settings 87
delete
alarm 65
all settings and favorites 87
all user data 87
call history 17
Favorites 37
message 49
picture 56
points from route 34
route 34
video 57
detour 33
device information 87

E

e-mail 50
emergency assistance 36
End key 1
enter data 11
Excel 66

F

Favorite
contact 18
delete 37
edit locations 37
locations 26
files
backup 70
exchange using FTP 74
restore 70
search for 70
send 74
file types
media gallery 56
music 54
find locations. *See* search for locations
flight mode 71, 99
flight status 22–23
forward 49
free map update 88
FTP 74
fuse, change 90

G

geocache 27

Go! page 20
go home 19
GPS
  about GPS 89
  new location 84
  settings 83
  turn off 84
  update 84
green LED 7

H

headphone jack 91
help 7
Hold key 1
hold phone call 14
home location 19
Home screen 5
  icons 77
  layout 77
  theme 77

I

icons 8
input panel 11
Internet 51
  share connection with computer 51
intersections, find 27

L

LED 7
letter recognizer 11
lithium-ion battery 88, 91
local events 23
local search 25
location-based service 29
location format 83
location information 20
  change update method 40
  send updates 83
location messages 48
lock the phone 7, 76

M

make a phone call 13
map
  additional 88
  browse 36
  customize 80
  detail level 80
  map set 38
  orientation 80
  update 88
  view 80
map datum 83
map settings 80
MapSource 88
map update 88
maximum speed, reset 32
Media Gallery 56–58
messages (SMS/MMS)
  delete 49
  forward 49
  new 47
  read 48
Microsoft Office
  Mobile 66
  Excel 66
  Excel Mobile 66
  OneNote Mobile 66
  PowerPoint Mobile 66
  Word Mobile 66
MMS 47
mount
  on windshield 3–4
  remove from mount 4
movie times 24
mute 6, 14

N

navigation. *See* route

Navigation key 6
network profile 79
news 46
  articles 52–53
Newstation 52–53
note 12
nüMaps Guarantee 88

O

odometer 32
off road route 81
OneNote 66
output, audio
  headphone jack 91

P

pacemakers 94
Panoramio 25
Panoramio photos 25
parking, find 24
phone 13–18
  receive a call 15
  settings 78–87
  sound settings 78
picture
  brightness 86
  effects 86
  file types 56
  quality 85
  take 59
  view 56
playlist 55
play music 54
position icon 81
Power key 1
PowerPoint 66
predictive text 11
profile 78
proximity points 82
  settings 82
puzzle lock 76

R

recalculate route 81
red LED 7
register i, 39
remove the mount 4
reply 48
reply to message 48
reset 88
  M20 88
  maximum speed 32
  odometer 32
  trip computer 32
restore all settings 87
restore files 70
ring settings 78
ring tone 78
  save a song as 55
  set 78
rotate screen 75
route
  add stops 33
  all turns in 31
  details 31
  edit 33, 34
  follow 30
  keep backlight on during 75
  next turn 31
  plan 34
  preferences 81
  save 33
  settings 80, 81
  simulate 35
  stop 33
  take saved route 34
  to appointment 29
  turn list 31
RSS 52–53

S

safe mode 82
safety cameras 45–46
  settings 82
SAR 95–96
satellite signals 84, 89
save location to
  Favorites 20
save your current
  location 33
screen
  align 75
  calibrate 75
  Home 5
  lock 7
  orient 75
  rotate 75
  use the touchscreen 6
search
  for files 70
  internet 51
search for locations 19
  address 19
  by category 21
  change the search
    area 21
  favorites 26
  fuel prices 22
  location options 20
  near a different city 21
  near a different
    location 21
  near your route 21
  points of interest 21
  spell name 21
send
  e-mail 50
  file 74
  found location 20, 28
  MMS 47
  SMS 47
  text 47
  your location 48
Send key 1
set a your current
  location 84
settings
  audio 82
  Connected Services 83
  phone 78–87
  route 81
set your location
  manually 84
SIM card
  copy contacts 18
  install 2
slideshow 57
SMS 47–50
  cell broadcast 80
software
  update 88
sound
  profile 78
  volume 6
speakerphone 14
specifications 91
speed limit 81
spell the location 21
Start menu 5, 7
status, Ciao! 40
status bar 65
  clock 65
  icons 8
storage information 97
stylus 6
suction cup 3
synchronize
  e-mail 50
  using Bluetooth
    technology 69
  using USB cable 68

with an Exchange Server 69
system information 87

T

text message 47–50
theft, ways to avoid 97
Today screen 5, 7
customize 77
track
edit 38
record 37
save 38
view on map 38
traffic 43–46
avoid 44–46
icon 44
transcriber 12
transfer file 74
trip computer 32
turn off phone 3, 71
turn preview 81

U

unit ID 87
units 82
update
maps 88
software 88
USB cable 1, 3, 51, 67, 68
USB Connection Mode 68
user data, delete 87

V

vehicle icon 81
vehicle type 81
vibrate 6, 78
video
call 16
file types 56
play 57
play a stream 58
play stream 58
record 60
settings 86–87
voicemail 15
voice note 12
voice prompt 82
volume 6
keys 6
video stream 58
Volume keys 1

W

wallpaper 77
weather 45–46
WebUpdater 88
Where Am I? 36
white pages 18, 46
Wi-Fi
set up 71
sharing 72
Wireless Manager 71
word completion 11
Word files 66

garmin asus

For the latest free software updates (excluding map data) throughout the life of your nüvifone, visit www.garminasus.com.

Windows® phone

September 2009 Part Number 190-01128-00 Rev. A Printed in China