

Flush Mount Template

Drill mounting holes 1/8" (3.0mm)

> 5.58" (141.6 mm)

 \circ

Unit outline

Cut the mounting surface along the inside of this line. Be very careful when cutting this hole; there is only a small amount of clearance between the unit and the mounting holes.



Drill a 3/8" hole, and begin cutting here.

- 1. Trim and tape this template to the mounting location. Avoid cable areas.
- 2. Drill four 1/8" (3 mm) mounting holes at the indicated locations.
- 3. Drill a 3/8" (10 mm) hole at the location indicated on this template, and then use the jig saw to cut the panel along the inside of the indicated line.
- 4. Install the four mounting studs into the unit by screwing the shorter section into the back of the unit.
- 5. Use a 0.05" Allen wrench to tighten the mounting studs until the stop contacts the case. Be careful not to overtighten, because this can damage the mounting stud! The studs have a reusable thread-locking patch pre-applied from the factory.
- 6. Place the unit into the cut out of the mounting surface.
- 7. Place washers over the mounting studs, and then thread on one hex nut per mounting stud.
- 8. Tighten all four hex nuts until the unit is snug against the mounting surface.
- 9. Install and tighten the second hex nut on all four mounting studs to lock the first one into place.

4.33" (110.0 mm)

April 2006