



GMX 200 Cockpit Reference Guide

1. Turn the power on (press **On** key). The screen will remain dark for a short time while the GMX 200 performs start-up and self-test operations. Press and hold **On/Off** key to turn power off.
2. Adjust the brightness, if necessary. Press **+** to increase brightness. Press **-** to decrease brightness. To return to automatic brightness control press and hold both the **+** and **-** keys for one second.
3. Check that all tests pass on the Start Up screen.
4. Press the **FN** key to view available functions. Each press of the **FN** key will step through the lists of available functions.
5. Press the "smart" key below the function label to select the desired function. Press the **FN** key again to view functions. See Figure A.
6. Once a function is selected, the function labels change to provide options for that function. Press the "smart" keys below the labels to choose options. See Figure B.
7. Once a function is selected, the **Menu/Enter** key is used to provide additional options. See Figure C.
8. Press the **Menu Item** key next to the displayed option to choose desired capabilities. Some options use multiple key presses for different states for the option. Press the **Menu/Enter** key again to extinguish the option display or it will extinguish automatically in 20 seconds. See Figure C.
9. The rotary knob complements the action of the function keys in some functions by pressing and turning the knob. Arrows will appear above the function keys indicating the direction to turn the rotary knob for the same effect. An accent mark in the function label indicates the function affected when the rotary knob is depressed.
10. Refer to the Detailed Operation section of the Pilot's Guide for more details on each function.



Terrain Color Key

Red	Terrain that is within 100 feet, at, or above, your current altitude.
Yellow	Terrain that is within 1000 ft of your current altitude.
Green	Terrain that is within 2000 ft of your current altitude.
Black	Terrain that is more than 2000 ft below your current altitude.
Light Blue	No terrain data is available.



GARMINTM

P/N 190-00607-03 Rev B
June 2007

1200 East 151st Street
Olathe, KS 66062-3426

USA (913) 397-8200
FAX (913) 397-8282
<http://www.garmin.com>

© 2007 by Garmin, Inc.
Printed in the U.S.A.
All Rights Reserved