



## Printing a Mounting Template

### NOTICE

These instructions for printing a mounting template must be followed precisely. Failure to do so may result in incorrect dimensions on the template and an incorrect cutout (too large or too small) on the mounting surface of your boat.

To print the attached mounting template, check the dimensions of the template and select the appropriate size of paper. Both the length and width measurements are indicated on the template.

The paper size must be larger than the dimensions of the template. Select the paper size using the **Properties** button in the Adobe Acrobat print dialog box.

Select **Auto-Rotate and Center** to ensure the template prints in the correct orientation.

**IMPORTANT:** When printing the flush mount template, set **Page Scaling** in the Adobe Acrobat print dialog box to **None**.

The screenshot shows the Adobe Acrobat Print dialog box with several annotations:

- Properties:** An arrow points to the **Properties** button in the top right corner of the dialog box.
- Page Scaling:** An arrow points to the **Page Scaling** dropdown menu, which is set to **None** and circled in red.
- Auto-Rotate and Center:** An arrow points to the **Auto-Rotate and Center** checkbox, which is checked.
- Paper size (example):** An arrow points to the **Paper: 8.5 x 11.0 in** text in the bottom right corner of the dialog box.

The **Print** dialog box includes the following sections:

- Printer:** Name: \\DLAWINPRINT\TECHPUBS8150-DUPL; Status: Ready; Type: HP LaserJet 8150 PS.
- Print Range:**  All;  Current view;  Current page; Pages from: 1 to: 1; Subset: All pages in range;  Reverse pages.
- Page Handling:** Copies: 1;  Collate; **Page Scaling:** None;  Auto-Rotate and Center;  Choose Paper Source by PDF page size.
- Preview:** Shows a preview of the mounting template with dimensions 11 (width) and 8.5 (height). Document: 10.4 x 7.9 in; Paper: 8.5 x 11.0 in; 1/1 (1).

### NOTICE

After printing and before cutting the mounting surface, measure the printed template to ensure both the length and the width printed at the correct size and to ensure that the dimensions of the printed template match the actual size of your mount. Garmin is not responsible for any damages or expenses resulting from a miscut mounting surface arising from a failure to follow these instructions.


# GARMIN®

## GPSMAP® 7015, 7215 Flush Mount Template

$\frac{9}{64}$  in.  
(3.5 mm)

$\frac{9}{32}$  in.  
(7.2 mm)

$\frac{3}{8}$  in.  
(9.5 mm)




Recommended clearance for sun cover handle  
 Espace de sécurité recommandé pour manipuler le pare-soleil  
 Spazio libero consigliato per la maniglia della copertura di protezione dai raggi solari  
 Empfohlener Abstand für Griff des Sonnenschutzes  
 Se recomienda despejar el mango de la cubierta para el sol  
 Folga recomendada para a pega da cobertura solar  
 Rekommenderat utrymme för solskyddshandtag  
 Anbefalet plads til soldækslets håndtag  
 Anbefalt klaring for håndtaket på soldekselet

$\frac{1}{2}$  in.  
13 mm

$11 \frac{5}{32}$  in.  
(283.2 mm)

Unit Dimensions:  $15 \frac{17}{32}$  in. (394.9 mm) W ×  $11 \frac{27}{32}$  in. (300.7 mm) H  
 Dimensions de l'appareil : 394,9 mm × 300,7 mm (L × H)  
 Dimensioni unità: L 394,9 mm × A 300,7 mm  
 Geräteabmessungen: Breite 394,9 mm × Höhe 300,7 mm  
 Dimensiones de la unidad: 394,9 mm ancho × 300,7 mm alto  
 Dimensões da Unidade: 394,9 mm L × 300,7 mm A  
 Enhetsmått: 394,9 mm B × 300,7 mm H  
 Enhedens mål: 394,9 mm B × 300,7 mm H  
 Mål på enheten: 394,9 mm B × 300,7 mm H



$5 \frac{13}{32}$  in.  
(138 mm)

$13 \frac{13}{64}$  in. (330.6 mm)

$14 \frac{39}{64}$  in. (370.6 mm)