

# MSN® Direct Receiver/GDB 55

*power cable and receiver*



© 2008 Garmin Ltd. or its subsidiaries

Garmin International, Inc.  
1200 East 151st Street,  
Olathe, Kansas 66062, USA  
Tel. (913) 397.8200 or (800) 800.1020  
Fax (913) 397.8282

Garmin (Europe) Ltd.  
Liberty House  
Hounslow Business Park,  
Southampton, Hampshire, SO40 9RB UK  
Tel. +44 (0) 870.8501241 (outside the UK)  
0808 2380000 (within the UK)  
Fax +44 (0) 870.8501251

Garmin Corporation  
No. 68, Jangshu 2nd Road,  
Shijr, Taipei County, Taiwan  
Tel. 886/2.2642.9199  
Fax 886/2.2642.9099

All rights reserved. Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express prior written consent of Garmin. Garmin hereby grants permission to download a single copy of this manual onto a hard drive or other electronic storage medium to be viewed and to print one copy of this manual or of any revision hereto, provided that such electronic or printed copy of this manual must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited.

Information in this document is subject to change without notice. Garmin reserves the right to change or improve its products and to make changes in the content without obligation to notify any person or organization of such changes or improvements. Visit the Garmin Web site ([www.garmin.com](http://www.garmin.com)) for current updates and supplemental information concerning the use and operation of this and other Garmin products.


Garmin® is a trademark of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These trademarks may not be used without the express permission of Garmin.

DirectBand, MSN, and the MSN logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

## Using MSN® Direct

The MSN Direct receiver provides MSN Direct content such as traffic, weather, gas prices, and movie times. For more information about MSN Direct, see <http://garmin.msndirect.com> or [www.garmin.com](http://www.garmin.com).

The MSN Direct receiver replaces the vehicle power cable/traffic receiver that came with your Garmin GPS navigator.



### To receive MSN Direct content:

- You must update the software on your Garmin GPS navigator (see [www.garmin.com](http://www.garmin.com)).
- Your MSN Direct receiver must be activated.

- The MSN Direct receiver must be connected to your Garmin GPS navigator and your vehicle's power outlet.
- You must be in an MSN Direct coverage area (see <http://garmin.msndirect.com/coverage>).



---

**WARNING:** See the *Important Safety and Product Information* sheet in your Garmin GPS navigator product box for product warnings and other important information. Garmin's standard Limited Warranty applies to this product.

---

## Activating MSN Direct



---

**NOTE:** When you first activate your receiver, you must specify a primary location and a current region. The primary location is the area you will use the device most often. The current region refers to your current location where the activation key will be broadcast.

---

To receive MSN Direct content, you must first activate

your service (1-year free service included). The product key is required to activate your subscription.

### To get the product key:

1. Connect the MSN Direct receiver to your Garmin GPS navigator and to your vehicle's power outlet. Turn your vehicle key to the ON/ACC position, if necessary, to power the Garmin GPS navigator.
2. On your Garmin GPS navigator, touch .



---

**NOTE:** Depending on the model of your Garmin GPS navigator, the MSN Direct Menu page could be accessible from your unit's Menu page or Tools page. Look for the  MSN icon on your unit.

---

3. Write down the product key.



---

**TIP:** The yellow tag on your MSN Direct receiver provides the product key and activation information. If the product key on the yellow tag differs from the one on your unit, use the product key on your unit.

---

### To activate your subscription:

1. Go to <http://garmin.msndirect.com/activate> or call (866) 658.7032 and follow the directions.
2. Within eight days, complete the following steps:
  - Connect the MSN Direct receiver to your vehicle power outlet, and turn the key to ON/ACC.
  - Make sure you are in an MSN Direct coverage area.
  - On your Garmin GPS navigator, touch . If the Subscription Inactive page appears, verify that at least one signal bar in the upper right corner is green . It may take up to one hour for your subscription to be activated. After it is activated, the MSN Direct Menu is accessible.

## MSN® Direct Menu



**NOTE:** The MSN Direct Menu page may look different depending on your GPS navigator.



**MSN Direct Menu Page**

On your Garmin GPS navigator, touch . If your subscription is inactive, see [page 4](#).

For traffic information, touch  on the Map page.

Touch **Status** to view the MSN Direct signal strength and the receiver's battery level. From the Status page, touch **Subscription** to view your subscription status.

## MSN Content



**NOTE:** Garmin is not responsible for the accuracy of the MSN Direct content.

The MSN Direct receiver provides MSN Direct content on your Garmin GPS navigator. For example, in some MSN Direct Coverage areas you can get detailed information on traffic delays and road closures. See <http://garmin.msndirect.com/whatyouget> for more information.

Additional MSN Direct content might include local events, stock information, and news.

For more information on MSN Direct content and features, read the MSN Direct Owner's Manual Supplement at [www.garmin.com](http://www.garmin.com).

## Receiving Content



---

**NOTE:** Heated (metalized) windshields could degrade the performance of the MSN® Direct receiver.

---

It can take several hours to receive all the content the first time you use the MSN Direct receiver, after you have traveled long distances, or after you have not used your MSN Direct Receiver for several days.

There is a (non-user replaceable) rechargeable battery in the MSN Direct receiver that allows it to receive and store updates for several days, even when not connected to external power.

## Customer Terms and Conditions for MSN Direct Service

“Coverage Area” means the areas of the United States and Canada (exclusive of U.S. Territories and Puerto Rico) in which the Service is available using the analog subcarrier broadcast of the Microsoft® DirectBand™ network – these

areas may change from time to time and coverage in a given geographic region may become unavailable. Coverage details are available at the following Web site (which may be updated from time to time): <http://garmin.msndirect.com/coverage>.

“Device” means the product you have purchased.

“DirectBand network” means the wide-area datacast network operated by Microsoft that uses FM radio broadcasts to deliver information within Coverage Area, and which will be available until at least January 1, 2012.

“Service” means the content and information provided via the Device pursuant to this Agreement. The Service and the DirectBand network may change from time to time. Such changes include, but are not limited to, removal of, additions to or changes to content delivered as part of the Service and Coverage Area. We do not promise that the Service or the DirectBand network will be available all the time. The Device should show text and other content provided over the DirectBand network if the Device is appropriately produced and configured by the Device manufacturer. The Service does not include sending data from Devices. The entire Service is subject to the disclaimers and limitations contained in this Agreement. Data is not necessarily real-time data. Certain elements of the Service may become unavailable.

**Reception Limitations:** Receipt of data is affected by the interruption of FM transmission, the relative strength of the signal, and reception limitations of the DirectBand™ network, as well as other factors such as your location within certain structures that may block FM signals (e.g., when you are in a garage).

The Service is only for use by the individual making use of the Device and is not for retransmission for commercial purposes. You will not use the Service in any way that is unlawful. You may not use the Service in any way that breaches any code of conduct or other notice applicable to the Service.

**NO WARRANTY:** WE PROVIDE THE SERVICE “AS IS,” “WITH ALL FAULTS” AND “AS AVAILABLE,” AND THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT IS WITH YOU. WE, OUR AFFILIATES, RESELLERS, DISTRIBUTORS, SERVICE PROVIDERS AND/OR SUPPLIERS, INCLUDING ENTITIES IN THE DIRECTBAND NETWORK (COLLECTIVELY, “GARMIN”) MAKE NO WARRANTIES. GARMIN DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS, STATUTORY AND IMPLIED, INCLUDING WITHOUT LIMITATION (1) WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, WORKMANLIKE EFFORT, ACCURACY, TITLE, QUIET ENJOYMENT, NO ENCUMBRANCES, NO LIENS AND NON-INFRINGEMENT, (2) WARRANTIES ARISING THROUGH COURSE OF DEALING OR USAGE OF TRADE, AND (3) WARRANTIES THAT ACCESS TO OR USE OF THE SERVICE WILL BE UNINTERRUPTED OR ERROR-FREE. THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE FACE OF THIS AGREEMENT. TO THE EXTENT PERMITTED BY LAW IN YOUR JURISDICTION, IN NO EVENT SHALL GARMIN BE LIABLE FOR ANY INDIRECT, CONSEQUENTIAL, SPECIAL, INCIDENTAL, OR PUNITIVE DAMAGES ARISING OUT OF, BASED ON, OR RESULTING FROM THIS AGREEMENT OR YOUR USE

OF THE SERVICE, EVEN IF GARMIN HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE EXCLUSION OF DAMAGES UNDER THIS SECTION IS INDEPENDENT OF ANY OTHER REMEDY AND SURVIVES IN THE EVENT ANY SUCH REMEDY FAILS OF ITS ESSENTIAL PURPOSE OR IS OTHERWISE DEEMED UNENFORCEABLE. THE LIMITATIONS AND EXCLUSIONS IN THIS SECTION APPLY WITHOUT REGARD TO WHETHER THE DAMAGES ARISE FROM (1) BREACH OF CONTRACT, (2) BREACH OF WARRANTY, (3) NEGLIGENCE, MISREPRESENTATION OR OTHER TORT, (4) PRODUCTS LIABILITY, OR (5) ANY OTHER CAUSE OF ACTION TO THE EXTENT NOT PROHIBITED BY APPLICABLE LAW. CHANGES TO THE SERVICE GARMIN MAY CHANGE THE SERVICE OR DELETE FEATURES IN ANY WAY, AT ANY TIME AND FOR ANY REASON.

Garmin or MSN® Direct may terminate or suspend the Service at any time, with or without cause, with or without notice. Upon termination of the Service, your right to use the Service will immediately cease, and Garmin will have no obligation to provide the Service to you.

For the latest free software updates (excluding map data) throughout the life of your Garmin products, visit the Garmin Web site at [www.garmin.com](http://www.garmin.com).



© 2008 Garmin Ltd. or its subsidiaries

Garmin International, Inc.  
1200 East 151<sup>st</sup> Street, Olathe, Kansas 66062, USA

Garmin (Europe) Ltd.  
Liberty House, Hounsdown Business Park, Southampton, Hampshire, SO40 9RB UK

Garmin Corporation  
No. 68, Jangshu 2<sup>nd</sup> Road, Shijr, Taipei County, Taiwan

[www.garmin.com](http://www.garmin.com)

Part Number 190-00935-02 Rev. B