

nüvi[®] 2505 series quick start manual

nüvi models: 2515, 2545, 2555, 2565, 2595



February 2012

190-01356-01_0C

Printed in Taiwan

Getting Started

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Setting Up Your Device

When using your device for the first time, complete the following tasks.

- 1 Connect the device to vehicle power (page 2).
- 2 Mount the device (page 2).
- **3** Register the device (page 3).
- 4 Check for updates.
 - Software updates (page 4).
 - Free map update (page 4).
- 5 Download the full owner's manual (page 4).

Connecting the Device to Vehicle Power

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, remove the device from the vehicle when exiting or store it out of direct sunlight.

NOTICE

Before mounting the device, see the *Important* Safety and Product Information guide for information about laws pertaining to windshield mounting.

Charge your device as you drive before using it on battery power.

- 1 Plug the vehicle power cable ① into the USB port ② on the device ③.
- 2 Press the suction cup ④ to the windshield.

3 While pressing, flip the lever (5) back toward the windshield.



- 4 Snap the mount ⁶ onto the suction cup.
- 5 Fit the bottom of your device into the mount.
- 6 Tilt your device back until it snaps into place.
- 7 Plug the other end of the vehicle power cable into a power outlet in your vehicle.
- 8 If necessary, connect the external antenna to the vehicle power cable and secure it to the windshield using the suction cups.

About myDashboard

You can use myDashboard to register your device, check for software and map updates, access product manuals and support, and more.

Setting Up myDashboard

1 Connect the mini-USB cable ① to the mini-USB port ② on the device (page 2).



- 2 Connect the mini-USB cable to the USB port on your computer.
- **3** Go to www.garmin.com/dashboard.
- **4** Follow the on-screen instructions.

Registering your Device

1 From myDashboard, click Register Now.

- 2 Follow the on-screen instructions.
- 3 Keep the original sales receipt, or a photocopy, in a safe place.

nüMaps Guarantee™

If you register the device at http://my.garmin .com within 90 days of acquiring satellites while driving, your device could be eligible for one free map update. Go to www.garmin.com/numaps for terms and conditions.

Using myDashboard Services

- 1 Open myDashboard (page 3).
- 2 Select an option:
 - To update the software, click **Update Now** under Software Updates.
 - To update the maps, click **Update Now** under Map Updates.
 - To download the owner's manual, click Manuals, and then click Download next to the manual you want.

3 Follow the on-screen instructions.

Using the Power Key



Select an option:

- To turn off the device, hold the **Power** key ① for 4 seconds.
- To reset the device, hold the **Power** key for 10 seconds.
- To put the device in sleep mode, press the **Power** key.
- To bring the device out of sleep mode, press the **Power** key and double-tap ⁽²⁾.

Finding a Location Using the Search Bar

You can use the search bar to search for locations by entering a category, brand name, address, or city name.

- 1 Select Where To?.
- 2 Select the search bar.



3 Enter a search term.

Suggested search terms appear below the search bar as you type.

- To search for a type of business, enter a category name, such as "movie theaters" or "coffee shops."
- To search for a business by name, enter all or part of the name.
- To search for an address near you, enter the street number and street name.

- To search for an address in another city, enter the street number, street name, city, and state.
- To search for a city, enter the city and state.
- To search for coordinates, enter latitude and longitude coordinates.
- 4 Select an option:
 - To search using a suggested search term, select the term.
 - To search using the text you entered, select **Q**.
- 5 If necessary, select a location.

Searching Near Another Location

From the main menu, select Where To? > Searching Near.

Adding a Stop

- 1 From the navigation screen, select > Points of Interest.
- 2 Search for the extra stop.
- 3 Select the stop from the search results.
- 4 Select Go!.
- 5 Select Add to Active Route.

Your Route on the Map

NOTICE

The speed limit icon feature is for information only and does not replace the driver's responsibility to abide by all posted speed limit signs and to use safe driving judgment at all times. Garmin will not be responsible for any traffic fines or citations that you may receive for failing to follow all applicable traffic laws and signs. Your route is marked with a magenta line on the map. If you depart from the original route, your device recalculates the route. A speed limit icon could appear as you travel on major roadways.



- Select ① to view the next turn.
 If a view of a junction exists, the junction view appears.
- Select 2 to view the turn list.
- Select ③ to stop the route you are currently navigating.
- Select ④ to view the Where Am I? page.

Taking a Detour

From the navigation page, select **Detour**.

If the route you are currently taking is the only reasonable option, the device might not calculate a detour.

About Traffic

NOTICE

Garmin is not responsible for the accuracy or timeliness of the traffic information.

Traffic information may not be available in all areas or countries. For information about traffic receivers and coverage areas, go to www .garmin.com/traffic.

A traffic receiver is included in some packages, built into either the vehicle power cable or the device, and is an optional accessory for all models.

- The device must be connected to vehicle power to receive traffic information.
- The powered traffic receiver and the device must be in data range of a station

transmitting traffic data to receive traffic information.

• You do not need to activate the subscription included with your traffic receiver.

Pairing Your Phone

Hands-free calling is available on some nüvi models. Before you can pair, your phone and the device must be turned on and within 33 ft. (10 m) of each other.

- 1 Enable the Bluetooth[®] component on your phone.
- 2 Select Settings > Bluetooth.
- 3 Select Bluetooth.
- 4 Select Add Phone > OK.
- 5 Select your phone, and touch OK.
- 6 Enter the Bluetooth PIN (1234) for your device in your phone.

www.garmin.com/support



913-397-8200 1-800-800-1020

00 32 2672 5254

0180 5 / 42 76 46 - 880 0180 5 / 42 76 46 - 550 00800 4412 454 +44 2380 662 915

Garmin International, Inc. 1200 East 151st Street, Olathe, Kansas 66062, USA

Garmin (Europe) Ltd.

Liberty House, Hounsdown Business Park Southampton, Hampshire, SO40 9LR UK

Garmin Corporation

No. 68, Zhangshu 2nd Road, Xizhi Dist. New Taipei City, 221, Taiwan (R.O.C.)



Garmin[®], the Garmin logo, and MapSource[®] are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. nüMaps Guarantee[™] is a trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth $^{\otimes}$ word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under license.

CE

© 2012 Garmin Ltd. or its subsidiaries