

GARMIN

nüLink!™ 2320/2340/2390 quick start manual



Getting Started

WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

When using your device for the first time, complete these tasks.

1. Connect the device to vehicle power ([page 3](#)).
2. Mount the device ([page 4](#)).
3. Register the device ([page 5](#)).
4. Check for updates:
 - Software updates ([page 5](#)).
 - Free map update ([page 6](#)).
5. Download the full owner's manual ([page 6](#)).

Power Cables

The device comes with two power cables. Each connector fits in only the matching port.

- The vehicle power cable ① connects the mount to vehicle power. The vehicle power cable has a right-angle connector.
- The micro-USB cable ② connects the device to a computer. A “B” is inscribed on the head of the micro-USB cable.



Connecting the Device to Vehicle Power

WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, remove the device from the vehicle when exiting or store it out of direct sunlight.

Before you use your device on battery power, you should charge it.

1. Fit the bottom of your device into the mount.
2. Tilt your device back until it snaps into place.




3. Plug the vehicle power cable **1** into the USB connector **2** on the mount or device.




4. Plug the other end of the vehicle power cable into a power outlet in your vehicle.

After the device has been connected to vehicle power, the following occurs.

- The device turns on.
- The device acquires satellite signals. When at least one of the  bars is green, your device has acquired satellite signals.

NOTE: The device may need a clear view of the sky to acquire satellite signals.

- The device charges as you drive.  in the status bar indicates the status of the internal battery.

Mounting Your Device

NOTICE

Before mounting the device, see the *Important Safety and Product Information* guide for information about laws pertaining to windshield mounting.

1. Remove the clear plastic from the suction cup.
2. Clean and dry your windshield and the suction cup with a lint-free cloth.
3. Press the suction cup to the windshield.
4. While pressing, flip the lever back toward the windshield.
5. Snap the mount ① onto the suction cup arm ②.




About myDashboard

You can use myDashboard to register your device, check for software and map updates, access product manuals

and support, and more.

Setting Up myDashboard

1. Connect the micro-USB cable ① to the micro-USB port ② on the device (page 2).



2. Connect the micro-USB cable to the USB port on your computer.
3. Go to www.garmin.com/dashboard.
4. Follow the on-screen instructions.

Registering the Device

1. From myDashboard, click **Register Now**.
2. Follow the on-screen instructions.
3. Keep the original sales receipt, or a photocopy, in a safe place.

Updating the Software

1. Open myDashboard (page 5).
2. Under Software Updates, click **Update Now**.
3. Follow the on-screen instructions.

nüMaps Guarantee™

If you register the device at <http://my.garmin.com> within 60 days of acquiring satellites while driving, your device could be eligible for one free map update. Go to www.garmin.com/numaps for terms and conditions.

Updating Maps

1. Open myDashboard (page 5).
2. Register the device (page 5).
3. Under Map Updates, click **Update Now**.
4. Follow the on-screen instructions.

Downloading the Owner's Manual

The owner's manual for your device is available on the Garmin Web site.

1. Open myDashboard (page 5).
2. Click **Manuals**.
3. Click **Download** next to the manual you want.
4. Save the file to your computer.

Device Overview



①	Power key
②	microSD™ card slot


Turning Off the Device

1. Hold the **Power** key for four seconds.
2. Select **Off**.

Using the Main Menu



- Select ① to select a transportation mode.
- Select ② to find a destination.
- Select ③ to view the map.
- Select ④ to stop a route.
- Select ⑤ to detour a route
- Touch ⑥ to make a call when connected to a compatible mobile phone.
- Touch ⑦ to adjust the volume.


- Touch  to open the menu of tools and settings.

About Points of Interest

The detailed maps loaded in your device contain points of interest, such as restaurants, hotels, and auto services.

Finding a Point of Interest by Category

1. From the main menu, select **Where To? > Points of Interest**.
2. Select a category.
3. If necessary, select a subcategory.
4. Select a destination.
5. Select **Go!**.

You can select  > **Save** on this page to save the location to a Favorites folder on the device. Use the Favorites folder to save the location of your workplace, home, and other common destinations.

6. If necessary, select an option.
 - Select **Drive** to calculate a route you will navigate by driving.
 - Select **Walk** to calculate a route you will navigate by walking.
 - Select **Public Transit** to calculate a route that combines public transit and walking.
- NOTE:** You must have cityXplorer™ maps loaded to navigate using public transit. Go to www.garmin.com to purchase cityXplorer maps.
7. If necessary, select a route.

Your Route on the Map

NOTICE



The speed limit icon feature is for information only and does not replace the driver's responsibility to abide by all posted speed limit signs and to use safe driving judgment at all times. Garmin will not be responsible for any traffic fines or citations that you may receive for failing to follow all applicable traffic laws and signs.

Your route is marked with a magenta line on the map. If you depart from the original route, your device recalculates the route. A speed limit icon could appear as you travel on major roadways.





Using the Map Functions







- Select ① to view the next turn. If a view of a junction exists, the junction view appears.
- Select ② to view the turn list.
- Select ③ to view traffic information.
- Select ④ to zoom in and out.
- Select ⑤ to view the Where Am I? page.
- Select and drag ⑥ to view a different area of the map.
- Select ⑦ to return to the Main menu.
- Select ⑧ to change the data field.

- Select  to view trip information.
- Select  to change the speed limit if the speed limit shown on the map is incorrect or to report a safety camera.

About the Main Menu Toolbar

Icon	Description
	GPS signal status. Select and hold to view satellite information.
	Bluetooth® technology status (appears when connected to a compatible device.) Select to change Bluetooth settings.
	Transportation mode indicator. Select to choose a transportation mode.
	Current time. Select to change time settings.

Icon	Description
	myGarmin™ messages. Select to check messages.
	Current temperature. Select to view weather information.
	nūLink!™ services signal status.
	Battery status.

Using myTrends

As you drive with the device on, myTrends™ gathers information that allows the device to predict when you are traveling to a common destination, like your workplace or home. When myTrends is activated, the destination and estimated time of travel will appear in the navigation bar on the map. Traffic information may also appear in the navigation bar.

myTrends only works for locations that are saved as Favorites ([page 7](#)).

When myTrends information appears in the navigation bar, select the navigation bar to view route information.

Disabling myTrends


From the main menu, select **Tools > Settings > Navigation > Automobile > nüRoute > myTrends > Disabled.**

About nüLink! Services

nüLink! services may not be available in all areas or countries.

Your device includes a basic nüLink! subscription, which is activated when you first turn on your device. nüLink! services allow you to receive current information, such as weather updates, fuel prices, and flight times.

To use these features, you must have a current nüLink! subscription, and your device must be receiving a

nüLink! signal, represented by  in the toolbar.

For more information on nüLink! services, select **Tools > Help**, or refer to the *nüLink! 2320/2340/2390 Owner's Manual* (page 6).

Purchasing Additional nüLink! Services


Select **Tools > nüLink! Store.**

About Traffic

NOTICE

Garmin is not responsible for the accuracy or timeliness of the traffic information.

Traffic information may not be available in all areas or countries.

When you are receiving traffic information, a traffic icon appears in the upper-left corner of the map page. The traffic icon () changes color to indicate the severity of traffic

conditions on your route or on the road you are currently traveling.

If there is traffic on your route, the traffic icon shows how much time the traffic has added to your route. The delay time is already included in your estimated arrival time.

Pairing Your Phone

Before you can pair, your phone and the device must be turned on and within 33 ft. (10 m) of each other.

1. Enable the Bluetooth® component on your phone.
2. From the main menu, select **Tools > Settings > Bluetooth**.
3. Select **Bluetooth > Enabled > Save**.
4. Select **Add Phone > OK**.
5. Select your phone, and select **OK**.
6. Enter the Bluetooth PIN (**1234**) for your device in your phone.


nüLink! 2320/2340/2390 Quick Start Manual

About Sleep Mode

Use sleep mode to conserve battery power when your device is not in use. Sleep mode uses very little power, and a fully-charged battery can last for weeks when your device is in sleep mode.

Entering and Exiting Sleep Mode

Select an option:

- To cause the device to enter sleep mode, press the **Power** key to put the device in sleep mode.
- To bring the device out of sleep mode, press the **Power** key and double-tap .

Finding More Information

You can find more information about this product on the Garmin Web site.

- Go to www.garmin.com/ontheroad.
- Go to <http://buy.garmin.com> to purchase accessories.
- Select **Tools > Help**.

Contacting Garmin Product Support

- In the USA, go to www.garmin.com/support, or call Garmin USA at (800) 800.1020.
- In the UK, call Garmin (Europe) Ltd. at 0808 2380000.

- In Europe, go to www.garmin.com/support and click **Contact Support** for in-country support information, or contact Garmin (Europe) Ltd. by phone at +44 (0) 870.8501241.

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. cityXplorer™, myGarmin™, myTrends™, nüLink!™ and nüMaps Guarantee™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under license. microSD™ is a trademark of SD-3C, LLC.

CE0682



© 2011 Garmin Ltd. or its subsidiaries