

iQue[®] M3

integrated handheld

quick reference guide



Table of Contents

Warning	3	Save Places	12
Caution	4	Route to Home	13
Open the GPS Antenna	5	Take a Detour	13
Acquire Satellite Signals	5	Add Stops to Your Route	14
Find a Restaurant	6	Browse the Map.....	15
Follow Your Route	7	Tools	16
Find an Address	8	Change Settings	16
Find by Spelling	9	Mount the iQue M3	17
Search Near Other Places	9	Contact Garmin.....	17
Find Contacts	10	FCC Compliance.....	18
View Recent Finds	11	Limited Warranty	19

More Information


For more information about navigating with the iQue M3, touch **Help** on the main page of the QueNav software. For information about using the Windows Mobile™ software on your iQue M3, refer to the *iQue M3 Operating Instructions* on your Setup DVD-ROM.

Warning

Failure to avoid the following potentially hazardous situations could result in an accident or collision resulting in death or serious injury.

When installing the iQue M3 in a vehicle, place the unit securely so that it does not interfere with vehicle operating controls or obstruct the driver's view of the road (see diagram).

Do not mount where driver's field of vision is blocked.



Do not place unsecured on the vehicle dash.

Do not mount in front of an airbag field of deployment.

Always operate the vehicle in a safe manner. Do not become distracted by the iQue M3 while driving, and always be fully aware of all driving conditions. Minimize the amount of time spent viewing the screen of the iQue M3 while driving and use voice prompts when possible. Do not enter destinations, change settings,

or access any functions requiring prolonged use of the unit's controls while driving. Pull over in a safe and legal manner before attempting such operations.

When navigating, carefully compare information displayed on the iQue M3 to all available navigation sources, including information from street signs, visual sightings, and maps. For safety, always resolve any discrepancies or questions before continuing navigation.

The iQue M3 contains a non-user-replaceable, rechargeable lithium-ion battery. The battery may present a risk of fire or chemical burn if mistreated.

- Do not remove from the unit, heat unit above 140°F (60°C), or incinerate.
- Dispose of unit properly. Contact your local waste disposal department for information on properly disposing of lithium-ion batteries.

WARNING: This product, its packaging, and its components contain chemicals known to the State of California to cause cancer, birth defects, or reproductive harm. This Notice is being provided in accordance with California's Proposition 65. If you have any questions or would like additional information, please refer to our Web site at <http://www.garmin.com/prop65>.



Caution

Failure to avoid the following potentially hazardous situations may result in injury or property damage.

The iQue M3 is designed to provide you with route suggestions. It does not reflect road closures or road conditions, traffic congestion, weather conditions, or other factors that may affect safety or timing while driving.

Use the iQue M3 only as a navigational aid. Do not attempt to use the iQue M3 for any purpose requiring precise measurement of direction, distance, location, or topography. This product should not be used to determine ground proximity for aircraft navigation.

The Global Positioning System (GPS) is operated by the United States government, which is solely responsible for its accuracy and maintenance. The government's system is subject to changes which could affect the accuracy and performance of all GPS equipment, including the iQue M3. Although the iQue M3 is a precision navigation device, any navigation device can be misused or misinterpreted and, therefore, become unsafe.

Map Data Information: One of the goals of Garmin is to provide customers with the most complete and accurate cartography that is available to us at a reasonable cost. We use a combination of governmental and private data sources, which we identify in product literature and copyright messages displayed to the consumer. Virtually all data sources contain inaccurate or incomplete data to some extent. This is particularly true outside the United States, where complete and accurate digital data is either not available or prohibitively expensive.


Notice to State of California Drivers: California Vehicle Code Section 26708 (a) (1) provides that “No person shall drive any motor vehicle with any object or material placed, displayed, installed, affixed, or applied upon the windshield or side or rear windows.” Drivers in California should not use the suction mount on their windshield or side or rear windows. Garmin does not take any responsibility for any fines, penalties, or damages that may be incurred as a result of disregarding this notice. A disk for attaching the suction mount to a vehicle's dashboard is enclosed.

Open the GPS Antenna

To navigate with your iQue M3, open the GPS antenna and acquire satellite signals.

To open the GPS antenna:

1. Press down on the antenna release, located on the back of the iQue M3.
2. Gently pull the antenna up until it is parallel to the ground and it clicks into place.



Acquire Satellite Signals


Go outdoors where you have a clear view of the sky to acquire satellite signals. For troubleshooting information, refer to the *iQue M3 Operating Instructions* on your Setup DVD-ROM.

Main Page

When you open the GPS antenna, the main QueNav page appears. Press the **Que** button to return to this page at any time.



Find a Restaurant



Touch **Where to?**



Touch **Food, Hotels...**



Touch **Food & Drink.**



Touch to see more categories.

Touch **All Categories**, or select another category.




Touch the restaurant you want to go to.




Touch **Go!**

Follow Your Route

Follow the purple line on the Map page to your destination.



Stop your route

To stop following your route, touch . Then touch **Stop**.

Hear directions

To hear driving directions, touch . Or, press and hold the **Que** button.

View upcoming turns

Touch the directions bar to view the next turn. Touch **Arrival Time** to view all turns in the route.


View trip information

Touch **Speed** to view the Trip Computer page.


If you go off route

If you stray from the route shown on the map, the iQue M3 recalculates and gives new route instructions.


Find an Address




Touch **Where to?** > **Addresses**.



Select a state.



Touch **Spell City**. Enter a city name.



Enter the number of the address. Touch **Next**.



Enter the street name and select a street.



If necessary, touch the correct address.



Touch **Go!**.

Find by Spelling



Touch **Where to?** >
Food, Hotels...



Touch **Spell Name**.

You can also find by spelling in any search category.



Touch **Spell**.




Enter the place name.

Search Near Other Places

When searching for places, you can narrow your search by touching **Near**.



Touch **Where to?** >
Near.



Select an option.

Near Other—finds places near an item you specify on the map.

Near Current Road/Route—finds places near the road or route you are currently following.


Near Route Destination—finds places near the destination of the route you are currently following.

Find Contacts

You can assign a point on the map for any contact in your iQue M3 and create a route to the contact.




Touch **Where to?** > **Contacts**.



Select the contact's address.



Touch the contact you want to go to.




Select the correct address.




Touch **Go!**. Then touch **Yes**.

If an address does not appear in step 4, follow the instructions on the screen to select a GPS Location for the contact.

Edit Contacts



From the main page, touch **Tools** > **Manage My Data**.



Touch the contact you want to edit.



Touch **Contacts**.




Select an option and enter new information.

View Recent Finds

Your iQue M3 stores a list of the last 40 places you have recently searched for.




Touch **Where to?** > **Recent Finds**.



Select a place.

Save Places

You can save places you find so you can easily retrieve them later. All saved places are stored in My Locations.



Search for a place as described previously. Then touch **Options**.



Touch **Save to My Locations**. Then touch **OK**.

Save Your Current Location


To save your current location in My Locations, touch **Tools > Where Am I?** Then touch **Save**.

Find Saved Places

To find and go to your saved places, touch **Where to? > My Locations**.

Edit Saved Places

To change the name of a saved place or its symbol, touch **Tools > Manage My Data > My Locations**.




Touch the Location you want to edit.



Select an option. To delete the Location, touch **Delete**.

Route to Home

You can save a special place in My Locations called Home. Then, you can easily route to Home.



Touch **Where to?** > **Home**.



Select an option.

After you set your Home Location, you can route home by touching **Where to?** > **Home**.


To change your Home Location, delete Home from My Locations (see previous page). Then follow the steps above to set a new Home Location.

Take a Detour

To take a detour from a route, touch **Detour** on the main page.



Touch **Detour**.




Touch **Distance** or **Upcoming Turn** and select an option.

Add Stops to Your Route

You can add extra stops, called via points, to your route. Enter the places you want to go, and the iQue M3 can determine the most logical order for your stops. You must have an active route to add a via point.




Search for a place to add to your route. Then touch **Options**.




Touch **Add as via to current route**. Repeat these steps to add more stops.


Rearrange Stops




Touch **Tools > Route Details**. Then touch **Edit Vias**.



Tap a via point in the list to move it.




Touch **Sort** to arrange the points automatically.



Touch the arrows to move the point up or down. To delete it, touch **Delete**.

Browse the Map

To view other parts of the map beyond your current location, touch **Tools > Browse Map**. Touch the map anywhere to place an arrow on the map. Touch and drag the map to view other areas.




Touch to re-center the map on your location.


Touch to zoom in.

Touch to zoom out.

Touch and drag to zoom in on an area.

Touch to measure distance. Touch the first point on the map. Then touch the pin . Touch the place you want to measure to. View the distance in the bar at the bottom of the page.



Touch anywhere on the map. An arrow appears. Touch  to view information about that point.

Tools

Route Details

To view Route Details, touch **Arrival Time** on the Map page. You can also touch **Tools > Route Details**. From this page, touch any turn to view details about that turn. If you do not have an active route, Route Details are unavailable.

Trip Computer

To view the Trip Computer page, touch **Speed** on the map. You can also touch **Tools > Trip Computer**.

Where Am I?

To view the Where Am I? page, touch **Tools > Where Am I?**

Change Settings

From the main page, touch **Settings**.

Settings > Map

Change map orientation and other map settings.

Settings > System

Turn WAAS on and change units of measure.

Settings > Routing

Change vehicle type and change how routes are calculated.


Settings > Display

Adjust backlight and change text language and color mode.

Settings > Audio

Adjust volume and change voice language.

Mount the iQue M3



To install the suction mount:

1. Loosen the adjusting knobs (shown above). Then extend the mount and retighten the knobs.
2. Clean and dry the windshield and the suction cup with rubbing alcohol.
3. Make sure the suction lever is up (pulled away from the suction cup). Position the suction mount on your windshield. Press the suction cup firmly against the glass and rock it to remove as much air as possible.

4. Press the suction lever down toward the windshield.
5. Gently slide the iQue M3 down into the cradle until it clicks into place.
6. Loosen the adjustment knobs and re-position the mount, if necessary. Then tighten the knobs firmly.

To remove the suction mount from the windshield, pull the suction lever up away from the windshield. If necessary, pull the tab on the bottom of the suction cup toward you.

Contact Garmin

If you encounter any difficulty while using your iQue M3, or if you have any questions, in the U.S.A. contact Garmin Product Support at 913/397.8200 or 800/800.1020, Monday–Friday, 8 AM–5 PM Central Time; or by e-mail at support@garmin.com. In Europe, contact Garmin (Europe) Ltd. at 44/0870.8501241.

FCC Compliance

The unit complies with Part 15 of the FCC interference limits for Class B digital devices FOR HOME OR OFFICE USE. These limits are designed to provide more reasonable protection against harmful interference in a residential installation and are more stringent than “outdoor” requirements.

Operation of this device is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications if not installed and used in accordance with the instructions.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The unit does not contain any user-serviceable parts. Repairs should only be made by an authorized Garmin service center. Unauthorized repairs or modifications could result in permanent damage to the equipment and void your warranty and your authority to operate this device under Part 15 regulations.



Limited Warranty

This Garmin product is warranted to be free from defects in materials or workmanship for one year from the date of purchase. Within this period, Garmin will at its sole option repair or replace any components that fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor, provided that the customer shall be responsible for any transportation cost. This warranty does not cover failures due to abuse, misuse, accident, or unauthorized alteration or repairs.

THE WARRANTIES AND REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED OR STATUTORY, INCLUDING ANY LIABILITY ARISING UNDER ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, STATUTORY OR OTHERWISE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE.

IN NO EVENT SHALL GARMIN BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM THE USE, MISUSE, OR INABILITY TO USE THIS PRODUCT OR FROM DEFECTS IN THE PRODUCT. Some states do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you.

Garmin retains the exclusive right to repair or replace the unit or software or offer a full refund of the purchase price at its sole discretion. SUCH REMEDY SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY.

To obtain warranty service, contact your local Garmin authorized dealer or call Garmin Product Support for shipping instructions and an RMA tracking number. The unit should be securely packed with the tracking number clearly written on the outside of the package. The unit should then be sent, freight charges prepaid, to any Garmin warranty service station. A copy of the original sales receipt is required as the proof of purchase for warranty repairs.

Garmin International, Inc.
Tel. 913/397.8200

Garmin (Europe) Ltd.
Tel. 44/0870.8501241

Online Auction Purchases: Products sold through online auctions are not eligible for rebates or other special offers from Garmin. Online auction confirmations are not accepted for warranty verification. To obtain warranty service, an original or copy of the sales receipt from the original retailer is required. Garmin will not replace missing components from any package purchased through an online auction.

International Purchases: A separate warranty is provided by international distributors for units purchased outside the United States. This warranty is provided by the local in-country distributor, and this distributor provides local service for your unit. Distributor warranties are only valid in the area of intended distribution. Units purchased in the United States or Canada must be returned to the Garmin service center in the United Kingdom, the United States, Canada, or Taiwan for service.

**For the latest free software updates (excluding map data) throughout the life of your
Garmin products, visit the Garmin Web site at www.garmin.com.**



© Copyright 2005 Garmin Ltd. or its subsidiaries

Garmin International, Inc.
1200 East 151st Street, Olathe, Kansas 66062, U.S.A.

Garmin (Europe) Ltd.
Unit 5, The Quadrangle, Abbey Park Industrial Estate, Romsey, SO51 9DL, U.K.

Garmin Corporation
No. 68, Jangshu 2nd Road, Shijr, Taipei County, Taiwan

www.garmin.com

Part Number 190-00511-02 Rev. A